

MACHINE APPLICATION
HISTORICAL SECTION

201113 COPY

DEPARTMENT No. 54
JULY 17 1923

DO NOT REMOVE
RESEARCH DIVISION

LIST OF PARTS COMPLETE



FOR

Machine No. 99-12

THE SINGER MANUFACTURING COMPANY

99 K 3 Foot.

99 K 4 - Hand

99 K 12 (Solid wheel) for Electric Drive

HISTORICAL COPY
D. C. M. 51
1923

DO NOT REMOVE
LIST OF PARTS COMPLETE

FOR

MACHINE No. 99-12

*33651	Arm with 448A and 32503
2002	" Dowel Pin
33602	" Rock Shaft with 905E
905E	" " " Adjusting Screw
50046A	" " " Screw Centre (lower)
1512E	" " " " " " Nut
50047c	" " " " " (upper)
138E	" Screw
33603	" Shaft
32503	" " Bushing
448A	" " " Set Screw
2007	" Spool Pin
8879	" " " Washer (cloth)
33652	Balance Wheel, 2 1/4 in. pulley
*33653	Bed
32505	" Leg
1129E	" " Screw
256B	Clamp Stop Motion Clamp Screw
248A	" " " " Stop Screw
2020	" " " " Washer
32618	" " " Flanged Bushing
1148c	" " " " Set Screw
32619	Clamp Stop Motion complete, Nos. 248A, 256B, 1148c, 2020 and 32618
33663	Face Plate
33654	" " 33663 with 2827
203D	" " Screw
2827	" " Thread Guard with 8505
8505	" " " " Rivet
32507	Feed Bar with 1944
1944	" " Roller and Stud
315c	" " Screw Centre
1519E	" " " " Nut
32600	" Dog
191K	" " Screw
33609	" Forked Connection with 175B
175B	" " " Adjusting Screw

506811E
33628

8422	Thread Guard (head of arm).....
33634	“ Take-up Crank.....
1036c	“ “ “ Set Screw.....
33635	“ “ Lever.....
33636	Thread Take-up Lever complete, Nos. 33635, 33637 and 33638.....
50056E	Thread Take-up Lever Cap Screw.....
33637	“ “ “ Hinge Stud.....
33638	“ “ “ Link.....
50057c	“ “ “ “ Hinge Screw.....
32575	“ “ Spring.....
32576	“ “ “ Regulator.....
453c	“ “ “ “ Set Screw.....
32602	Throat Plate for 32600.....
691A	“ “ Screw.....

ACCESSORIES

36569	Oiler with 36571.....
36570	“ 36569, filled with oil.....
36571	“ Spout, 1¾ in. long, with 36807.....
36807	“ “ Washer (leather).....

ATTACHMENT SET

36594	Binder.....
25527B	Cloth Guide.....
287D	“ “ Thumb Screw.....
35931	Hemmer (adjustable).....
—	Needles.....
32522	Bobbin.....
25557	Screw Driver (machine).....
25538	“ “ (shuttle tension).....
36583	Tucker.....
120359	Attachment Set, Nos. 287B, 25527B, 25537, 25538, 35931, 36583, 36594, five 32522 and six needles
120290	Ruffler.....
120360	Attachment Set complete, Nos. 120290 and 120359

BOBBIN WINDER

(AUTOMATIC)

15376	Adjusting Arm.....
50058B	“ “ Screw.....
15072	Bobbin Position Pin.....
32604	Bracket (belt cover).....
180B	“ Screw.....

15413	Frame.....
32655	“ 15413 with 571c, 15288 and 32550.....
50059B	“ Hinge Screw.....
15286	“ Spring.....
15287	Friction Ring (rubber).....
15288	Pulley.....
32550	Spindle with 15072.....
571c	“ Worm.....
32625	Stop Latch.....
50230B	“ “ Hinge Screw.....
15291	“ “ Spring.....
32628	Thread Guide.....
50061B	“ “ Hinge Screw.....
15366	“ “ Spring.....
15416	Worm Wheel and Thread Guide Cam.....
2749	“ “ “ “ “ Friction Washer
50B	“ “ “ “ “ “ “ Screw Stud (eccentric).....
1528J	Worm Wheel and Thread Guide Cam Screw Stud Nut
32629	Bobbin Winder (automatic) complete, Nos. 50B, 1528J, 2749, 15286, 15287, 15291, 15366, 15376, 15416, 32604, 32625, 32628, 32655, 50058B, 50059B, 50061B and 50230B.....