

Form 3210W
(462)
Printed in U. S. A.

LIST OF PARTS COMPLETE

FOR


MACHINE NOS. 300W103 and 300W203

HISTORICAL COPY
SERIALIZED BY
MAY 11 1964
MILWAUKEE, WIS.

THE SINGER MANUFACTURING COMPANY

PARTS FOR MACHINE No. 300w103

LIST OF PARTS COMPLETE
FOR



MACHINE No. 300w103
TWO THREAD CHAIN STITCH
ONE NEEDLE. ONE LOOPER.
COMPOUND FEED.
ALTERNATING PRESSERS.
MAXIMUM STITCH 3 1/2 TO THE INCH
NEEDLE BAR STROKE 1 1/4 INCHES.
PRESSER BAR LIFT 3/8 INCH.

FOR WELTING, BINDING, MATTRESSES and SEAMING
MEDIUM and HEAVY FABRICS

No.	Plate	Name
*267501	-----	Arm with 201485C, 204235, 267602, 267635, 268004, two each 3554, 200030H, three each 200029E and 200047D
*267602	-----	Arm Head with 200351C and 200417C
204235	18640	" " Position Pin
200029E	18640	" " Screw
3582	18640	" " Position Pin (2)
200004E	18640	" " Screw (4)
267503	18632	" " Shaft with 268009, 268044, 268264, two each 268214 and 350534C
268024	18632	Arm Shaft Ball Bearing (back)
268004	18632	" " " " " " Housing
200047D	18632	" " " " " " Screw
268005	18632	" " " " " " (front)
268006	18632	" " " " " " (front) neoprene
268006	18632	Arm Shaft Connection Belt Pulley with two each 201254C and 201253
201254C	18632	Arm Shaft Connection Belt Pulley Set Screw

No.	Plate	Name
202253	18632	Arm Shaft Connection Belt Pulley Spring Flange
268732	18632	Arm Shaft Counter Balance with 200354C and 200362C
200354C	18632	Arm Shaft Counter Balance Position Screw
200362C	18632	" " " " " " Set Screw
268264	18632	" " " " Oil Control Rod (wood)
268008	18632	" " " " Slinger with 350171C
350171C	18632	" " " " " " Set Screw
268214	18632	" " " " Stop Ball, 5.32 in. diameter
350534C	18632	" " " " " " Screw
268009	18632	" " " " " " Spring (front)
268044	18632	" " " " " " (rear)
267604	18640	" " Side Cover
267661	18640	" " " " Oil Shield with 244411 and 267662
267662	18640	Arm Side Cover Oil Shield Pin
244411	18640	" " " " " " Staple
200078H	18640	" " " " " " Screw (4)
268048	18632	Balance Wheel "V" belt groove (outside diam. of belt groove 2.9 in.) with 200342C and 200347C
268049	18632	Balance Wheel 268048 with 268024
200342C	18632	" " " " Position Screw
200347C	18632	" " " " Set Screw
*268401	-----	Bed with 268184, two each 200035E and 226887
265307	18640	" " Hinge Connection (L)
200553H	18640	" " " " " " Screw (4)
267505	18640	" " Plate (left)
268018	18640	" " " " (right)
200053H	18640	" " " " " " Screw (8)
267600	18640	" " " " Side with two 268022 and four 200164H
268022	18640	Bed Plate Slide Spring
200164H	18640	" " " " " " Screw
263160	18633	" " Shaft with 268044, 268214, 268265 and 350534C
268024	18632	Bed Shaft Ball Bearing
268028	18633	" " " " Connection Belt Pulley with two 201254C
268261	18633	Bed Shaft Connection Belt Pulley 268024 with 268024
201254C	18632	Bed Shaft Connection Belt Pulley Set Screw
268732	18633	" " " " Counter Balance with 200354C and 200362C
200354C	18632	Bed Shaft Counter Balance Position Screw
200362C	18632	" " " " " " Set Screw
268024	18632	" " " " Needle Bearing (2)
268265	18633	" " " " Oil Control Rod (wood)
350534C	18633	" " " " " " Screw
268044	18632	" " " " " " Spring
268006	18632	Face Plate with 268006, 268007, 268008 and 201411C
268006	18640	Face Plate Hinge Pin (2)
201411C	18640	" " " " " " Set Screw
200353C	18640	" " " " " " (long)
268032	18640	" " " " Lock Spring

PARTS FOR MACHINE No. 300w103

No.	Plate	Name
268197	18640	Face Plate Lock Spring Plate
200571XC	18640	" " " " Screw (2)
268033	18640	" " " Stud
268034	18634	Feed Bar with 200373C and two 200403C
268035	18634	" " " " Hinge Pin
202574	18634	" " " " Collar with 200380C
200380C	18634	" " " " Set Screw
200403C	18634	" " " Set Screw
268618	18643	" Dog with 268318 and two 200172D, for 268614
200100C	18643	Feed Dog Screw (2)
268318	18634	" " Shank with 201537H and 350552C
350552C	18634	" " " Adjusting Screw
201537H	18634	" " " " Lock Nut
200040AL	18634	" " " " Screw
201525E	18634	" " " " Lock Nut
208636	18634	" " " " Washer
267608	18634	" Driving Connection
267609	18634	" " " 267608 with 271055
268652	18634	" " " " Hinge Stud with 268258
201522E	18634	Feed Driving Connection Hinge Stud Nut
268258	18634	" " " " " Oil Packing (wick)
271055	18634	Feed Driving Connection Needle Bearing
267610	18633	" " " Eccentric
268065	18633	" " " Adjusting Disc
268066	18633	" " " " " "
		Spring
268067	18633	Feed Driving Eccentric Adjusting Disc Spring
		Collar with two 200382C
200382C	18633	Feed Driving Eccentric Adjusting Disc Spring Collar Set Screw
267623	18633	Feed Driving Eccentric Friction Plate
350548C	18633	" " " " " " Screw
350477C	18633	" " " " " " " "
		Set Screw
		Feed Driving Eccentric Friction Plate Screw
		Set Screw Packing (brass)
268215	18633	Feed Driving Flange with 267623, two each 241763, 350467AL, 350477C and 350548C
241763AL	18633	Feed Driving Flange Set Screw
268064	18634	" " " " Rock Frame with 200094C and 200382C
		Feed Driving Rock Frame Position Screw
200152C	18634	" " " " " Set Screw
268073	18634	" " " " Shaft
268072	18634	" " " " " Collar with two 200386C (2)
200061D	18633	Feed Driving Rock Shaft Collar Set Screw
268073	18634	" " " " " Crank with 201418C and two 200061C
200061C	18634	Feed Driving Rock Shaft Crank Pinch Screw
201418C	18634	" " " " " Position Screw
268071	18634	" " " " Needle Bearing (2)
268072	18634	" Lifting Connection
268062	18634	" " " " Hinge Stud with 268258
267608	18634	Feed Lifting Connection Hinge Stud Nut

PARTS FOR MACHINE No. 300w103

No.	Plate	Name
268258	18634	Feed Lifting Connection Hinge Stud Oil Packing (wick)
268075	18634	Feed Lifting Crank with 200373C and 201256C
201256C	18634	" " " " Pinch Screw
268047	18635	" " " Eccentric with 268077 and two 200394C
268077	18635	Feed Lifting Eccentric Lubricating Pad (wood)
200394C	18635	Feed Lifting Eccentric Set Screw
268078	18634	" " " Link
268079	18634	" " " " Hinge Pin with 268258 (2)
268258	18634	" " " " " Oil Packing (wick)
200373C	18634	Feed Lifting Link Hinge Pin Set Screw
268080	18634	" " " Rock Shaft
268072	18634	" " " " " Collar with two 200386C (2)
200386C	18634	Feed Lifting Rock Shaft Collar Set Screw
268198	18634	" " " " " Crank with 201418C and two 200061C
200061C	18634	Feed Lifting Rock Shaft Crank Pinch Screw
201418C	18634	" " " " " Position Screw
268071	18634	Feed Lifting Rock Shaft Needle Bearing (2)
268081	18633	" Regulating Stud
240245	18633	" " " Retaining Spring
268082	18633	" " " " Socket
200073F	18633	" " " " " Screw (2)
270026	18633	" " " " Spring
267611	18638	Foot Lifter Arm with 200058C and 200373C
200058C	18638	" " " " Pinch Screw
200373C	18638	" " " " Set Screw
267512	18638	" " " Crank
200650H	18638	" " " " Stop Screw Stud
268085	18638	" " " Lever (back) with 238089
201363C	18638	" " " " " Hinge Screw
204348	18638	" " " " Spring
201495C	18638	" " " " " " Screw
201160E	18638	" " " " " " Eye
267612	18638	" " " " (front) with 267614
267614	18638	" " " " " Hinge Pin
203941	18638	" " " " " Spring
201052	18638	" " " " " " Screw
350524X	18638	" " " " Rod Hinge Screw
201525E	18638	" " " " " " Nut
206133	18638	" " " " " Washer
267615	18638	" " Rod
267616	18638	Lifting Crank with 200157E, 200418C and two 200061D
200061D	18638	Lifting Crank Pinch Screw
200418C	18638	" " " " Set Screw
268064	18632	" Eccentric
268065	18632	" " Adjusting Disc
267618	18632	" " " " Spring
267619	18632	" " " Connection
267620	18632	" " " " 267618 with 268065

PARTS FOR MACHINE No. 300w103

No.	Plate	Name
267645	18638	Presser Bar Spring Arm Fork Lock Washer (nylon)
267646	18638	Presser Bar Spring Arm Fulcrum
201254C	18638	" " " " " " Set Screw (2)
267647	18638	Presser Bar Spring Arm Hinge Buffer (leather)
267648	18638	Presser Bar Spring Housing
267660	18638	Presser Bar Spring Housing complete, Nos. 200186H, 267641, 267644, 267645, 267648, 267651, 267652, 267654 and 267655
201524E	18638	Presser Bar Spring Housing Adjusting Nut (2)
200378C	18638	Presser Bar Spring Housing Oil Screw
244084	18638	" " " " " " " " Set Screw
200378C	18638	" " " " " " " " Packing (fibre)
200378C	18638	Presser Bar Spring Housing Support with 200378C and 244084
267670	18638	Presser Bar Spring Housing Support Retainer
200064F	18638	" " " " " " " " Screw (2)
267651	18638	Presser Bar Spring Plunger
267652	18638	" " " " " " " " Bearing with 267653
267653	18638	Presser Bar Spring Plunger Bearing Bushing (oil retaining)
267654	18638	Presser Bar Spring Plunger Cap
267655	18638	" " " " " " " " Washer (leather)
268162	18605	Spreader with 268162
268163	18605	" " " " " " " " Bar
268164	18605	" " " " " " " " Bearing
268165	18605	" " " " " " " " Position Pin
200100E	18605	" " " " " " " " Screw
200100E	18605	" " " " " " " " Driving Connection with two 201020E
268186	18605	Spreader Driving Connection 268186 with 200100E and 200100E
200364C	18605	Spreader Driving Connection Cap Screw
268187	18605	" " " " " " " " Needle Bearing
200403C	18605	" " " " " " " " Crank with 200364C and 200403C
200403C	18605	Spreader Driving Crank Position Screw
200403C	18605	" " " " " " " " Set Screw
200364C	18605	" " " " " " " " Eccentric with two 200364C
200364C	18605	" " " " " " " " Counter Balance with two 200364C
200364C	18605	Spreader Driving Eccentric Counter Balance Set Screw
268188	18605	Spreader Driving Eccentric Set Screw
268189	18605	" " " " " " " " Thrust Washer (2)
268190	18605	Spreader Driving Pin
268191	18605	" " " " " " " " Rock Shaft
268192	18605	" " " " " " " " Collar with two 200364C (2)

PARTS FOR MACHINE No. 300w103

No.	Plate	Name
200386C	18605	Spreader Driving Rock Shaft Collar Set Screw
268071	18605	Spreader Driving Rock Shaft Needle Bearing (2)
350466C	18605	Spreader Driving Rock Shaft Screw Stud
351876	18605	" " " " " " " " Ball Roller
201736E	18605	Spreader Driving Rock Shaft Screw Stud Nut
268185	18605	" " " " " " " " Holder with two 200380C
200380C	18605	" " " " " " " " Set Screw
200100E	18605	" " " " " " " " Point
350149C	18605	" " " " " " " " Screw
204925	18605	" " " " " " " " Washer
267656	18640	Thread Lubricator with 50608R, 139017, 350549C and three 236957
236957	18640	Thread Lubricator Oil Pad (felt)
350549C	18640	" " " " " " " " Regulating Screw
50608R	18640	" " " " " " " " Plug Screw
139017	18640	" " " " " " " " Washer
200064D	18640	" " " " " " " " Screw
268614	18640	Throat Plate for 268618
200100E	18640	" " " " " " " " Screw (3)
267657	18638	Vibrating Presser Bar
267658	18638	" " " " " " " " Hinge Stud
267659	18640	" " " " " " " " Foot with 200078F and 267632
200078F	18640	Vibrating Presser Foot Pinch Screw

PARTS FOR MACHINE No. 300w203

MACHINE No. 300w203

TWO THREAD CHAIN STITCH

TWO NEEDLES. TWO LOOPERS.
COMPOUND FEED.

ALTERNATING PRESSERS.
MAXIMUM STITCH 3 1/2 TO THE INCH

NEEDLE BAR STROKE 1 1/4 INCHES.
PRESSER BAR LIFT 3/4 INCH.

FOR LAP SEAM FELLING and INSERTING SLEEVES
in SPORT SHIRTS and SIMILAR WORK in
MEDIUM and HEAVY FABRICS

MADE IN GAUGES FROM 1 1/4 TO 1 INCH

Same as Machine No. 300w201, with the following
exceptions:

No.	Plate	Name
267300	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 1, 4 and 7, 32 in. (teeth cut 15 to the inch) with two 268317 and four 200172D, for 267350
267302	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 1, 4, 9, 32 and 5, 16 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267351
267304	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 12, 3, 8 and 13, 32 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267353
267312	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 7, 15, 15, 32 and 1/2 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267355
267317	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges from 11, 32 to 21, 32 in. in steps of 1/32 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267357
267321	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges from 11, 16 to 31, 32 in. in steps of 1/32 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267358
267325	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in 1 in. gauge (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267359
267326	18644	Lifting Presser Foot, for 267329, in gauges from 3, 16 to 11, 32 in. in steps of 1/32 in. with 200073F
267377	18644	Lifting Presser Foot, for 267380, in gauges from 3, 16 to 11, 32 in. in steps of 1/32 in. with 200073F

No.	Plate	Name
268317	18644	Loop Deflector
268088	18639	Looper (2)
268103	18639	" Holder, in gauges from 3/16 to 11, 32 in., in steps of 1/32 in., with four 350478C
268104	18639	Looper Holder, in gauges from 1/8 to 5/8 in. in steps of 1/32 in., with four 350478C
268105	18639	Looper Holder, in gauges from 21, 32 to 7/8 in., in steps of 1/32 in., with four 350478C
268106	18639	Looper Holder, in 20, 31, 15, 16, 31, 32 and 1 in. gauge, with four 350478C
268296	18639	Looper Thread Guide (on Bed at Looper) for gauges from 1, 16 to 15, 32 inch
268297	18639	Looper Thread Guide (on Bed at Looper) for gauges from 1, 16 to 35, 32 inch
268298	18639	Looper Thread Guide (on Bed at Looper) for gauges from 13, 16 to 1 inch
268121	18642	Looper Thread Tension Spring, Size 4
5099	18642	Looper Thread Tension Spring, Size 14
268136	18637	Needle Bar
268219	18639	" Rock Frame Thread Guide, in gauges from 1, 16 to 11, 32 in. in steps of 1/32 inch
268254	18639	Needle Bar Rock Frame Thread Guide, in gauges from 1, 16 to 11, 32 in. in steps of 1/32 inch
268255	18639	Needle Bar Rock Frame Thread Guide, in gauges from 21, 32 to 7/8 in. in steps of 1/32 inch
268256	18639	Needle Bar Rock Frame Thread Guide, in 20, 32, 15, 16, 31, 32 and 1 in. gauge
268151	18639	Needle Holder, in gauges from 1, 16 to 11, 32 in., in steps of 1/32 in., with two 50014C
268152	18639	Needle Holder, in gauges from 3, 8 to 1, 8 in., in steps of 1/32 in., with two 50014C
268154	18639	Needle Holder, in gauges from 11, 12 to 7, 8 in., in steps of 1/32 in., with two 50014C
268156	18639	Needle Holder, in 20, 32, 15, 16, 31, 32 and 1 in. gauge, with two 50014C
50014C	18639	Needle Set Screw
226206	18642	" Thread Tension Releasing Pin (2)
54279	18642	" Thread Guide
268173	18639	Spreader, in 20, 32, 15, 16, 31, 32 and 1 in. gauge, with two 268162
268175	18639	Spreader, in gauges from 1, 4 to 5, 8 in. in steps of 1/32 in., with two 268162
268176	18639	Spreader, in gauges from 21, 32 to 7, 8 in. in steps of 1/32 in., with two 268162
268180	18639	Spreader, in 20, 32, 15, 16, 31, 32 and 1 in. gauge, with two 268162
267850	18644	Throat Plate, for 267300, in gauges 1, 16 and 1, 32 inch
267851	18644	Throat Plate, for 267312, in gauges 1, 4, 2, 32 and 1, 16 inch
267853	18644	Throat Plate, for 267304, in gauges 11, 32, 3, 8 and 13, 32 inch

PARTS FOR MACHINE No. 300w203

No.	Plate	Name
267855	18644	Throat Plate, for 267812, in gauges 7/16, 15/32 and 1/2 inch
267857	18644	Throat Plate, for 267817, in gauges from 17/32 to 21/32 in., in steps of 1/32 inch
267858	18644	Throat Plate, for 267821, in gauges from 11/16 to 31/32 in., in steps of 1/32 inch
267859	18644	Throat Plate, for 267825, in 1 in. gauge
267679	18644	Vibrating Presser Foot, 40 needle hole, in gauges from 3/16 to 11/32 in., in steps of 1/32 in., with 200078F. for 267676
267680	18644	Vibrating Presser Foot, 40 needle hole, in gauges from 3/8 to 1 in., in steps of 1/32 in., with 200078F. for 267677

ACCESSORIES

ACCESSORIES

FOR MACHINE No. 300w103

FOOT LIFTER TREADLE

No.	Plate	Name
62x59	-----	Needles, six, size 22
228443	18612	Drip Pan
200019E	18612	" " Screw (2)
410805	18612	" " Washer (2)
52843	18612	" " " " (leather) (4)
384280	18611	Looper and Needle Bar Setting Gauge
264276	18611	" Threading Wire
131961	18612	Machine Base Oil Drain Jar (glass)
131962	18612	" " " " " Cap
131138	18612	" " " " " Clamp
131217	18612	" " " " " " 131188 with 131139
131189	18612	Machine Base Oil Drain Jar Clamp Lever
1247C	18612	" " " " " " Screw
131266	18612	" " " " " " Nipple (short)
128462	18612	Machine Base Oil Drain Jar complete, Nos. 131217, 131266, 131961, 131962 and two 1247C
228320	18645	Machine Cushion (felt) (4)
228444	18645	" " (neoprene) (4)
41400	18611	" Rest Pin (wood)
228449	18645	" Support (left) with two wood screws 1-1/4 in., No. 12, F. H. B.
228450	18645	Machine Support (right) with two wood screws 1-1/4 in., No. 12, F. H. B.
228491	18611	Pressure Oiler
228498	18611	Screw Driver (7-1/4 in. long)
255542	18611	" " (8 in. blade)
228476	18611	" " (Bobbin Case)
27739	18611	Thread Cone (wood) (2)
201511	18611	Wrench
228900	18611	Wrench
249820	18611	Wrench
255540	18611	" (steel)

FURNISHED ONLY WITH MACHINES ORDERED

FOR BEA ORDERED INSTALLATION

41401	-----	Machine Rest Pin (wood) (in place of 41400)
228460	-----	" Support (left) with two wood screws 1-1/4 in., No. 12, F. H. B. (in place of 228449)
228461	-----	Machine Support (right) with two wood screws 1-1/4 in., No. 12, F. H. B. (in place of 228450)

No.	Plate	Name
228716	18646	Treadle
228474	18646	" Chain, 34 in. long, with two 202784
202784	18646	" " Hook
14373	18646	" Extension
50581R	18646	" " Screw
2718R	18646	" " Washer
17881	18646	" Shaft
14374	18646	" Spring
14375	18646	" Stand
228717	18646	Foot Lifter Treadle complete, Nos. 2718R, 14373 to 14375, 17881, 50581R and 2718R

THREAD UNWINDER
FOR TWO SPOOLS

228647	18627	Base with two 209341C
228692	18627	Spool Pin
201528H	18627	" " Nut
228693	18627	" " Washer
225257	18627	" Rest (for two spools) (flat with 201018C, two each 201528H, 228692 and 228693)
150203	18627	Spool Rest Cushion (felt)
228648	18627	" " Rod
200341C	18627	" " " " Set Screw
201018C	18627	" " " " Set Screw
228649	18627	Thread Tube with two 268127
268125	18627	" " Bushing
350101AL	18627	" " " " Set Screw
228649	18627	" " " " Set Screw
350101AL	18627	" " " " Set Screw
201129H	18627	Thread Tube Support Set Screw
228650	18627	Thread Unwinder complete, for two spools, Nos. 228657, 228647, 228649, 228649, 228649, each 150203, 228649, and three 4-1/4 in. screws 1-1/4 in., No. 14, F. H. B.

FOR MACHINE No. 300w103

Same as Machine No. 300w103 with the following exceptions:

50159	18611	Needles, six, size 22
27739	18611	Thread Cone (wood) (4)

ACCESSORIES

THREAD UNWINDER
FOR FOUR SPOOLS

No.	Plate	Name
228647	18628	Base with two 200341C
228692	18628	Spool Pin
201528H	18628	" " Nut
228692	18628	" " Washer
225257	18628	" Rest (for two spools) (flat) with 201015C, two each 201328H, 228692 and 228693
180207	18628	Spool Rest Cushion (felt)
228648	18628	" " Rod
200341C	18628	" " " Set screw
201015H	18628	" " " Set Screw
228652	18628	" " Stud
228651	18628	" " Support with 201128H, two 228652 and eight 350101AL
201128H	18628	Spool Rest Support Set Screws
228647	18628	Thread Tube with tv. 228125
228125	18628	" " Bushing
350101AL	18628	" " Bar screw
228652	18628	Three 1/2" x 1" x 1/4" complete, for four spools, Nos. 228647, 228648, 228651, two 225257, four each 180203, 228649 and three wood screws 1-1/4 in., No. 14, r. H. B.

FEED DOGS

FOR MACHINE No. 300w103

267814	18644	Feed Dog with 268318 and two 200172D, for 268614
--------	-------	---

FOR MACHINE No. 300w203

267800	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 3, 16 and 7, 32 in. (teeth cut 15 to the inch) with two 268317 and four 200172D, for 267850
267851	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 1, 4, 7, 32 and 5, 16 in steps of 1/2 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267851

FEED DOGS

No.	Plate	Name
267804	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 11, 32, 3, 3 and 13, 32 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267853
267812	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges 7, 16, 16, 32 and 1, 32 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267855
267817	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges from 17, 32 to 21, 32 in., in steps of 1/2 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267857
267821	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in gauges from 17, 16 to 21, 32 in., in steps of 1/2 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267858
267825	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in 1 1/2" gauge, teeth cut 15 to the inch with two 268318 and four 200172D, for 267859
267815	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 22, in 1 1/2" gauge, teeth cut 15 to the inch with two 268318 and four 200172D, for 267859
267819	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 24, in gauges 11, 32, 3, 3 and 13, 32 in. (teeth cut 5 to the inch) with two 268318 and four 200172D, for 267857
267826	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 24, in gauges 11, 32, 3, 3 and 13, 32 in. (teeth cut 15 to the inch) with two 268318 and four 200172D, for 267855
267831	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 24, in gauges 7, 16, 16, 32 and 1, 32 in. (teeth cut 5 to the inch) with two 268318 and four 200172D, for 267855
267834	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 24, in gauges from 17, 32 to 21, 32 in., in steps of 1/2 in. (teeth cut 5 to the inch) with two 268318 and four 200172D, for 267857
267835	18644	Feed Dog, 46 needle hole, for needle sizes 20 and 24, in gauges from 17, 16 to 21, 32 in., in steps of 1/2 in. (teeth cut 5 to the inch) with two 268318 and four 200172D, for 267857
267837	18644	Feed Dog, 40 needle hole, for needle sizes 20 and 24, in gauges from 17, 32 to 21, 32 in., in steps of 1/2 in. (teeth cut 5 to the inch) with two 268318 and four 200172D, for 267857

FEED DOGS

No.	Plate	Name
267838	18644	Feed Dog, 40 needle hole, for needle sizes 23 and 24, in 1 in. gauge (teeth cut 8 to the inch) with two 268218 and four 200172D, for 267859

LOOPER HOLDERS

FOR MACHINE No. 300w103

268602	18616	Looper holder with two 350478C
--------	-------	--------------------------------

FOR MACHINE No. 300w203

268103	18638	Looper holder, in gauges from 3 to 11 32 in. in steps of 1 32 in., with four 350478C
268104	18639	Looper holder, in gauges from 1 3 to 5 32 in., in steps of 1 32 in., with four 350478C
268105	18639	Looper holder, in gauges from 21 32 to 7 8 in., in steps of 1 32 in., with four 350478C
268106	18639	Looper holder, in 29 32, 15 16, 31 32 and 1 in. gauge, with four 350478C

LOOPER THREAD GUIDES

(on Bed at Looper)

FOR MACHINE No. 300w103

268296	18616	Looper Thread Guide (on Bed at Looper)
--------	-------	--

FOR MACHINE No. 300w203

268295	18639	Looper Thread Guide (on Bed at Looper) for gauges from 3 16 to 15 32 inch
268297	18639	Looper Thread Guide (on Bed at Looper) for gauges from 1 2 to 25 32 inch
268294	18639	Looper Thread Guide (on Bed at Looper) for gauges from 15 16 to 1 inch

NEEDLE BAR ROCK FRAME
THREAD GUIDES

FOR MACHINE No. 300w103

No.	Plate	Name
268219	18616	Needle Bar Rock Frame Thread Guide

FOR MACHINE No. 300w203

268219	18639	Needle Bar Rock Frame Thread Guide, in gauges from 3 16 to 11 32 in. in steps of 1 32 in.
268254	18639	Needle Bar Rock Frame Thread Guide, in gauges from 1 3 to 5 32 in. in steps of 1 32 in.
268255	18639	Needle Bar Rock Frame Thread Guide, in gauges from 21 32 to 7 8 in. in steps of 1 32 in.
268256	18639	Needle Bar Rock Frame Thread Guide, in 29 32, 15 16, 31 32 and 1 in. gauge

NEEDLE HOLDERS

FOR MACHINE No. 300w203

268151	18639	Needle Holder, in gauges from 3 16 to 11 32 in., in steps of 1 32 in., with two 500140
268152	18639	Needle Holder, in gauges from 3 8 to 15 32 in., in steps of 1 32 in., with two 500140
268154	18639	Needle holder, in gauges from 21 32 to 7 8 in., in steps of 1 32 in., with two 500140
268155	18639	Needle holder, in 29 32, 15 16, 31 32 and 1 in. gauge, with two 500140

DRESSED FEET

FOR MACHINE No. 300w103

267632	18643	Lifting Presser Foot with 200075F for 267634
267631	18643	Vibrating Presser Foot with 200075F for 267632

PRESSER FEET

FOR MACHINE No. 300w203

No.	Plate	Name
267676	18644	Lifting Presser Foot, for 267679, in gauges from 3/16 to 11/32 in., in steps of 1/32 in., with 200078F
267677	18644	Lifting Presser Foot, for 267680, in gauges from 3/8 to 1 in., in steps of 1/32 in., with 200078F
267679	18644	Vibrating Presser Foot, 40 needle hole, in gauges from 3/16 to 11/32 in., in steps of 1/32 in., with 200078F, for 267676
267680	18644	Vibrating Presser Foot, 40 needle hole, in gauges from 3/8 to 1 in., in steps of 1/32 in., with 200078F, for 267677

SPREADERS

FOR MACHINE No. 300w103

268006	18616	Spreader with 268162
--------	-------	----------------------

FOR MACHINE No. 300w203

268177	18639	Spreader, in gauges from 3/16 to 11/32 in., in steps of 1/32 in., with two 268162
268178	18639	Spreader, in gauges from 3/8 to 5/8 in., in steps of 1/32 in., with two 268162
268179	18639	Spreader, in gauges from 21/32 to 7/8 in., in steps of 1/32 in., with two 268162
268180	18639	Spreader, in 29/32, 15/16, 31/32 and 1 in. gauge, with two 268162

THROAT PLATES

FOR MACHINE No. 300w103

268614	18643	Throat Plate, for 268618
--------	-------	--------------------------

THROAT PLATES

FOR MACHINE No. 300w203

No.	Plate	Name
267850	18644	Throat Plate, for 267800, in gauges 3/16 and 7/32 inch
267851	18644	Throat Plate, for 267802, in gauges 1/4, 9/32 and 5/16 inch
267853	18644	Throat Plate, for 267804, 267815 and 267819, in gauges 11/32, 3/8 and 13/32 inch
267855	18644	Throat Plate, for 267811, 267823 and 267817, in gauges 7/16, 15/32 and 1/2 inch
267857	18644	Throat Plate, for 267817 and 267834, in gauges from 17/32 to 21/32 in., in steps of 1/32 inch
267858	18644	Throat Plate, for 267821, 267835 and 267837, in gauges from 11/16 to 31/32 in., in steps of 1/32 inch
267859	18644	Throat Plate, for 267845 and 267858, in 1 in. gauge