

SINGER
107W17

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the PART number in the FIRST column.

The number stamped on a Sewing Machine Part is the number of the Single Part only, except when the part includes Set Screws, Clamping Screws, Studs and Rollers Spun on, Small Wires riveted, or Parts soldered together, etc., which it is necessary to furnish in combination.

Every combination of parts sent out has its specific number which, although not stamped on Parts (except in above case) must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever Machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A	Hardened, Polished, Nickel Plated and Buffed.
AL	Heat Treated for Toughness.
ALX	Heat Treated for Toughness and Black Oxide.
B	Polished, Nickel Plated and Buffed.
C	Hardened only.
D	Polished only.
E	Soft, Not polished.
F	Hardened and Polished.
J	Nickel Plated only.
R	Merlized
X	Black Oxide, for Iron and Steel.
XC	Hardened and Black Oxide, for Iron and Steel.
Y	Black Nickel Plated only.
Z	Chromium Plated.

These letters MUST BE USED when they appear in the list and AFTER the number, as in the list.

In this series:

1 to 1500, 200001 to 201500 and 350001 to 351500 are Screw Numbers.
1501 to 1800, 201501 to 201800 and 350501 to 351800 are Nut Numbers.
1801 to 2000, 201801 to 202000 and 350801 to 352000 are Roller Numbers.
2001 to 50000 and 202001 to 350000 are Numbers of Machine Parts.

The figures in the second column refer only to the plate in which the illustration of the part is shown and are NOT TO BE USED in ordering. These Plates are in Form 20500, Illustrations of Parts.

Parts marked with an asterisk (*) are furnished only when repairs are made at the factory.

LIST OF PARTS COMPLETE
 FOR
 MACHINE NO. 107w17
 LOCK STITCH. SHORT ARM. TWO NEEDLES.
 DROP FEED. ZIGZAG.
 MAKES TWO ROWS OF STITCHES FOR GAUGES
 FROM 1/32 TO 7/32 INCH.
 MAXIMUM STITCH 5 TO THE INCH.
 FOR ORNAMENTING SPORT CLOTHES,
 SHOES, GLOVES. ETC.

No.	Plate	Name
*242151	-----	Arm with 202135
242102	18902	Arm Cap
200278X	18902	Arm Cap Screw
202248	18902	Arm Cap Screw Washer
204235	16826	Arm Position Pin (2)
200004E	16826	Arm Screw
200010E	16826	Arm Screw (2)
202005	16826	Arm Screw Washer (3)
202249	18902	Arm Shaft with 224392 and 350431E
240802	18902	Arm Shaft Bushing (back) with 202244
202244	18902	Arm Shaft Bushing (back) Oil Packing (wick)
200338C	18902	Arm Shaft Bushing (back) Set Screw
207080	18902	Arm Shaft Bushing (front) with 202244
202244	18902	Arm Shaft Bushing (front) Oil Packing (wick)
200502X	18902	Arm Shaft Bushing (front) Oil Packing Thumb Screw
200341C	18902	Arm Shaft Bushing (front) Set Screw
224400	16000	Arm Shaft Connection Belt (reinforced neoprene)
202635	16826	Arm Shaft Connection Belt Pulley with 200327C, 200602C and two 202253
200602C	16826	Arm Shaft Connection Belt Pulley Position Screw
200327C	16826	Arm Shaft Connection Belt Pulley Set Screw
202253	16826	Arm Shaft Connection Belt Pulley Spring Flange
224392	18902	Arm Shaft Oil Packing (wick)
350431E	18902	Arm Shaft Oil Packing Stop Screw
*210504	-----	Bed
210844	16826	Bed Hinge Connection (2)
200060E	16826	Bed Hinge Connection Screw (4)
210505	16002	Bed Plate (back)
200577AL	16002	Bed Plate (back) Screw (2)
210616	16002	Bed Slide (front)

PARTS FOR MACHINE NO. 107w17

No.	Plate	Name
263099	18908	Bobbin
210846	18908	Bobbin Case Base
242103	18908	Bobbin Case Cap with 200592C, 201016C and 242105
242104	18908	Bobbin Case Cap complete, Nos. 200964C, 210736, 210914 and 242103
210913	18908	Bobbin Case Latch
210914	18908	Bobbin Case Latch 210913 with 210734 and 210735
210735	18908	Bobbin Case Latch Fulcrum Pin
210734	18908	Bobbin Case Latch Lever
210736	18908	Bobbin Case Latch Spring
200964C	18908	Bobbin Case Latch Stop Screw
210764	16827	Bobbin Case Stop
200076D	16827	Bobbin Case Stop Screw
242105	18908	Bobbin Case Tension Spring
201016C	18908	Bobbin Case Tension Spring Regulating Screw
200592C	18908	Bobbin Case Tension Spring Screw
242106	18908	Bobbin Case complete, Nos. 210846 and 242104
242139	16895	Face Plate
202135	16895	Face Plate Position Pin
200462X	16002	Face Plate Thumb Screw
210512	18926	Feed Bar
242189	18926	Feed Bar 210512 with 266005 and 266011
266005	18926	Feed Bar Hinge Stud (eccentric)
200988F	18926	Feed Bar Hinge Stud Set Screw
202276	16827	Feed Bar Slide Block
210514	16827	Feed Bar Slide Block Crank with 200035E
210515	16827	Feed Bar Slide Block Crank 210514 with 200253C, 201531E and 202276
200035E	16827	Feed Bar Slide Block Crank Pinch Screw
200253C	16827	Feed Bar Slide Block Hinge Screw
201531E	16827	Feed Bar Slide Block Hinge Screw Nut
210518	16838	Feed Dog, for 210600
200106E	16898	Feed Dog Screw (2)
202297	18913	Feed Driving Connection with 200054E and 203101
202624	16827	Feed Driving Connection Crank with 200038C
200038C	16827	Feed Driving Connection Crank Pinch Screw
200545C	16826	Feed Driving Connection Hinge Screw
201518E	16826	Feed Driving Connection Hinge Screw Nut
203101	18913	Feed Driving Connection Oil Packing (wick)
200054E	16826	Feed Driving Connection Pinch Screw
202300	16826	Feed Driving Eccentric Regulating Bracket
203098	16826	Feed Driving Eccentric Regulating Bracket 202300 with 202635, two each 201014C and 201525E
201014C	16826	Feed Driving Eccentric Regulating Bracket Hinge Screw
201525E	16826	Feed Driving Eccentric Regulating Bracket Hinge Screw Nut
202301	16826	Feed Driving Eccentric Regulating Bracket Plunger

PARTS FOR MACHINE NO. 107w17

No.	Plate	Name
202595	16826	Feed Driving Eccentric Regulating Bracket Plunger Spring
200607C	16826	Feed Driving Eccentric Regulating Bracket Plunger Spring Stop Screw
201014C	16826	Feed Driving Eccentric Regulating Bracket Stop Screw
201525E	16826	Feed Driving Eccentric Regulating Bracket Stop Screw Nut
200429F	16826	Feed Driving Eccentric Regulating Screw
200383C	16826	Feed Driving Eccentric Regulating Screw Check Screw
266011	18926	Feed Driving Rock Shaft with two 200988F
202625	16827	Feed Driving Rock Shaft Stop Collar with two 200383C (2)
200383C	16827	Feed Driving Rock Shaft Stop Collar Set Screw
202306	18913	Feed Lifting Connection with 200054E and 203101
*210645	-----	Feed Lifting Connection Crank
210589	16827	Feed Lifting Connection Crank 210645 with 200050C and 200378C
200050C	16827	Feed Lifting Connection Crank Pinch Screw
200378C	16827	Feed Lifting Connection Crank Set Screw
202307	18902	Feed Lifting Connection Eccentric with 200382C and 200437C
200437C	18902	Feed Lifting Connection Eccentric Position Screw
200382C	16827	Feed Lifting Connection Eccentric Set Screw
200545C	16826	Feed Lifting Connection Hinge Screw
201518E	16826	Feed Lifting Connection Hinge Screw Nut
203101	18913	Feed Lifting Connection Oil Packing (wick)
200054E	16826	Feed Lifting Connection Pinch Screw
210531	16827	Feed Lifting Rock Shaft (hollow) and Hook Driving Shaft Bearing
202625	16827	Feed Lifting Rock Shaft Stop Collar with two 200383C
200383C	16827	Feed Lifting Rock Shaft Stop Collar Set Screw
202310	18902	Feed Regulating Spindle with 202311, 202443 and 202169
*202311	-----	Feed Regulating Spindle Head
202443	18902	Feed Regulating Spindle Head Pin
202619	18902	Feed Regulating Spindle Head Position Pin
224432	18908	Hook (sewing) with 203101 and 263134
224433	18908	Hook 224432 with 200145C, 210536, 210541 and three 200596F
224459	18908	Hook and Bobbin Case complete, Nos. 224433 and 242106
210614	16827	Hook Driving Bevel Pinion (steel) 24 teeth, with two 200378C
200378C	16827	Hook Driving Bevel Pinion Set Screw
210535	16827	Hook Driving Bevel Pinion Shaft
202661	16827	Hook Driving Bevel Pinion Shaft Belt Pulley with 202324 and two 200378C
200378C	16827	Hook Driving Bevel Pinion Shaft Belt Pulley Set Screw
202324	16827	Hook Driving Bevel Pinion Shaft Belt Pulley Spring Flange
210536	18908	Hook Gib
200596F	18908	Hook Gib Screw

PARTS FOR MACHINE NO. 107w17

No.	Plate	Name
203101	18913	Hook Oil Wick
263134	18908	Hook Oiling Felt
200915F	16827	Hook Position Screw
210537	16827	Hook Shaft (hollow)
210615	16827	Hook Shaft Bevel Gear (steel) 24 teeth, with two 200382C
200382C	16827	Hook Shaft Bevel Gear Set Screw
210539	16827	Hook Shaft Bushing
210621	16827	Hook Shaft Bushing 210539 with 210537 and 350314F
200335C	16827	Hook Shaft Bushing Set Screw
200363AL	16827	Hook Shaft Bushing Set Screw
244084	16004	Hook Shaft Bushing Set Screw Packing (fibre)
350314F	16827	Hook Shaft Position Screw
210541	18908	Hook Washer Needle Guard
200145C	18908	Hook Washer Needle Guard Screw
240067	16002	Knee Lifter Connection Lever
210876	16002	Knee Lifter Connection Lever 240067 with 202447, 210875 and two 200262X
200262X	16002	Knee Lifter Connection Lever Hinge Screw
202447	16002	Knee Lifter Connection Lever Lifting Rod with 202302
202302	16002	Knee Lifter Connection Lever Lifting Rod Cotter Pin
210875	16002	Knee Lifter Lifting Lever
200262X	16002	Knee Lifter Lifting Lever Hinge Screw
244090	18913	Machine Pulley (disc) (aluminum alloy casting) "V" belt groove (outside diam. of belt groove 2.9 in.) with 350540C and 350541C
350540C	18913	Machine Pulley Position Screw
350541C	18913	Machine Pulley Set Screw
242108	16896	Needle Bar
210543	18910	Needle Bar Connecting Link
202333	18910	Needle Bar Connecting Link Stud with 202299
202299	18910	Needle Bar Connecting Link Stud Oil Packing (wick)
200383C	16826	Needle Bar Connecting Link Stud Set Screw
200374AL	18910	Needle Bar Connecting Link Stud Set Screw
210544	18910	Needle Bar Connecting Stud with 202299
210585	18910	Needle Bar Connecting Stud 210544 with 210882
202299	18910	Needle Bar Connecting Stud Oil Packing (wick)
210882	18910	Needle Bar Connecting Stud Swivel with 200387C
210725	18910	Needle Bar Crank with 200335C, 200374AL, 200383C, 300428C and 202333
203172	16896	Needle Bar Crank Friction Washer
200428C	18910	Needle Bar Crank Position Screw
200335C	16827	Needle Bar Crank Set Screw
242109	16896	Needle Bar Frame with 200070C
210547	16896	Needle Bar Frame Guide Stud
200334C	16896	Needle Bar Frame Guide Stud Set Screw
210548	16896	Needle Bar Frame Hinge Stud
200334C	16896	Needle Bar Frame Hinge Stud Set Screw
242153	16897	Needle Bar Frame Pitman

PARTS FOR MACHINE NO.107w17

No.	Plate	Name
210557	16897	Needle Bar Frame Pitman Eccentric Stud
200070C	16896	Needle Bar Frame Pitman Eccentric Stud Set Screw
242142	18925	Needle Bar Frame Pitman Screw Stud
242143	18925	Needle Bar Frame Pitman Screw Stud Indicator
1658C	18267	Needle Bar Frame Pitman Screw Stud Nut
7070	16897	Needle Bar Frame Pitman Screw Stud Sleeve
200387C	18910	Needle Bar Set Screw
242122	16893	Needle Holder Body with 201030AL
201030AL	16893	Needle Holder Screw
242123	16893	Needle Holder Slide (left) with 200130F
242124	16893	Needle Holder Slide (right) with 200130F
200130F	16896	Needle Holder Slide Screw
200130F	16896	Needle Set Screw
242125	16893	Needle Holder complete (adjustable from 1/32 to 7/32 in.) Nos.242122 to 242124 and two 200130F
*266103	-----	Needle Vibrator Bracket
202602	16897	Needle Vibrator Bracket Position Pin (2)
200048D	16897	Needle Vibrator Bracket Screw (4)
242206	18925	Needle Vibrator Cam (Domino Stitch) (No.6)
201517C	16897	Needle Vibrator Cam Lock Nut
214892	16897	Needle Vibrator Cam Lock Nut Washer
266105	16897	Needle Vibrator Cam Shaft with 249739
203244	16897	Needle Vibrator Cam Shaft Collar with two 200393C
200393C	16897	Needle Vibrator Cam Shaft Collar Set Screw
249952	18906	Needle Vibrator Cam Shaft Gear
266106	16897	Needle Vibrator Cam Shaft Gear Friction Washer
249739	16897	Needle Vibrator Cam Shaft Gear Position Pin
249738	16897	Needle Vibrator Cam Spacing Washer
242171	18901	Needle Vibrator Gear
350471C	18901	Needle Vibrator Gear Lock Screw
242172	18901	Needle Vibrator Gear Position Spring
242145	18925	Needle Vibrator Guard
201304E	18925	Needle Vibrator Guard Screw
350129E	16897	Needle Vibrator Guard Screw
249725	18901	Needle Vibrator Intermediate Gear, 36 teeth
266109	18901	Needle Vibrator Intermediate Gear Adjusting Arm
200961X	18901	Needle Vibrator Intermediate Gear Adjusting Arm Hinge Screw
201533E	18901	Needle Vibrator Intermediate Gear Adjusting Arm Hinge Screw Nut
350261C	18901	Needle Vibrator Intermediate Gear Adjusting Arm Lock Stud
201694D	18901	Needle Vibrator Intermediate Gear Adjusting Arm Locking Thumb Nut
202622	18901	Needle Vibrator Intermediate Gear Adjusting Arm Locking Thumb Nut Washer
266110	18901	Needle Vibrator Intermediate Gear Bracket with 200054E
200054E	16826	Needle Vibrator Intermediate Gear Bracket Pinch Screw

PARTS FOR MACHINE NO.107w17

No.	Plate	Name
350449C	18901	Needle Vibrator Intermediate Gear Screw Stud
201617E	18901	Needle Vibrator Intermediate Gear Screw Stud Nut
266111	18901	Needle Vibrator Intermediate Gear Screw Stud Washer
266112	16897	Needle Vibrator Rock Shaft
242150	18925	Needle Vibrator Rock Shaft Lever with 200054E, 201531E, 202600 and 242147
200054E	16826	Needle Vibrator Rock Shaft Lever Pinch Screw
201865	-----	Needle Vibrator Rock Shaft Lever Roller
242146	-----	Needle Vibrator Rock Shaft Lever Roller Screw Stud
242147	18925	Needle Vibrator Rock Shaft Lever Roller Screw Stud 242146 with 201865
201531E	16827	Needle Vibrator Rock Shaft Lever Roller Screw Stud Nut
202600	16897	Needle Vibrator Rock Shaft Lever Roller Screw Stud Washer
242190	18925	Needle Vibrator Rock Shaft Lever Spring
201136E	18925	Needle Vibrator Rock Shaft Lever Spring Screw Stud
242174	16897	Needle Vibrator Rock Shaft Lever Timing Indicator
200124X	16897	Needle Vibrator Rock Shaft Lever Timing Indicator Screw (2)
242148	18925	Needle Vibrator Segment Lever with two 200394C
242149	18925	Needle Vibrator Segment Lever Index Plate
200133X	18925	Needle Vibrator Segment Lever Index Plate Screw
200394C	16897	Needle Vibrator Segment Lever Set Screw
266034	18902	Needle Vibrator Worm with two 200382C
266035	18901	Needle Vibrator Worm Gear with two 200382C
235299	18901	Needle Vibrator Worm Gear Friction Washer
200382C	16827	Needle Vibrator Worm Gear Set Screw
242175	18901	Needle Vibrator Worm Gear Shaft
210551	18901	Needle Vibrator Worm Gear Shaft Bearing and Cover
200566D	18901	Needle Vibrator Worm Gear Shaft Bearing Screw (4)
249067	18901	Needle Vibrator Worm Gear Shaft Oiling Tube
200382C	16827	Needle Vibrator Worm Set Screw
244033	16889	Presser Bar (hollow)
202335	16889	Presser Bar 244033 with 200074F
207072	16889	Presser Bar Bushing
200352C	16889	Presser Bar Bushing Set Screw
202554	16889	Presser Bar Lifter
200653C	16889	Presser Bar Lifter Hinge Screw
210789	16889	Presser Bar Lifting Releasing Lever Bracket
200260E	16889	Presser Bar Lifting Releasing Lever Bracket Guide Screw
206608	16889	Presser Bar Lifting Releasing Lever Bracket Spring
202337	16889	Presser Bar Position Guide
202338	16889	Presser Bar Position Guide Lever with 200086F
200086F	16889	Presser Bar Position Guide Lever Pinch Screw
200352C	16889	Presser Bar Position Guide Set Screw

PARTS FOR MACHINE NO.107w17

No.	Plate	Name
202343	16889	Presser Bar Spring (light)
202346	16889	Presser Bar Spring Stop Rod
200492X	16889	Presser Bar Thumb Screw (pressure regulating)
200475X	16004	Presser Bar Thumb Screw Thumb Set Screw
244084	16004	Presser Bar Thumb Screw Thumb Set Screw Packing (fibre)
202090	18926	Presser Foot Hinge Pin
242185	18926	Presser Foot Plate
242186	18926	Presser Foot Shank
242187	18926	Presser Foot Yielding Plate (center)
202090	18926	Presser Foot Yielding Plate (center) Hinge Pin
242188	18926	Presser Foot Yielding Plate (center) Spring
242184	18926	Presser Foot (hinged) with Yielding Plate (center) complete, Nos. 242185 to 242188 and two 202090
200074F	16889	Presser Foot Screw
242140	16893	Take-up (auxiliary)
200132E	16896	Take-up (auxiliary) Screw
248258	18925	Take-up Lever
202399	18910	Take-up Lever Driving Stud with 202277
202277	18910	Take-up Lever Driving Stud Oil Packing (wick)
202400	18910	Take-up Lever Hinge Stud with 202423
202423	18910	Take-up Lever Hinge Stud Oil Packing (wick)
200383C	16826	Take-up Lever Hinge Stud Set Screw
202401	16889	Take-up Lever Oiling Felt
200132E	16896	Take-up Lever Oiling Felt Screw
234086	18102	Tension Bracket with two each 200397X, 201224B and 236060
200159F	18102	Tension Bracket Screw
234047	18102	Tension Bracket Screw Socket
200368X	18912	Tension Bracket Screw Socket Set Screw
236098	18102	Tension Bracket Thread Guide
200174X	18102	Tension Bracket Thread Guide Screw
234087	18102	Tension Bracket complete, Nos. 200174X, 200978X, 201199F, 223703, 223706, 234086, 236098, 237174, two each 13710, 200309E, 204059, 204271, 223704, three 201572X and four 244048
244048	18102	Tension Disc
236060	18102	Tension Disc Position Pin
223703	18102	Tension Release Lever
235072	16889	Tension Release Lever Rod
200309E	18102	Tension Release Lever Screw
223704	18102	Tension Release Plunger
204271	18102	Tension Release Washer
13710	18102	Tension Spring
201224B	18102	Tension Stud
201572X	18102	Tension Thumb Nut
223706	18102	Thread Controller Disc
200978X	18102	Thread Controller Disc Screw

PARTS FOR MACHINE NO.107w17

No.	Plate	Name
237174	18102	Thread Controller Spring
241360	18102	Thread Controller Spring Stop
200132E	18102	Thread Controller Spring Stop Screw
201199F	18102	Thread Controller Stud with 204925
200061ALX	18102	Thread Controller Stud Set Screw
201572X	18102	Thread Controller Stud Thumb Nut
204925	18102	Thread Controller Stud Washer
242126	16886	Thread Guide (lower)
242127	16893	Thread Guide (on Needle Bar Frame)
200174X	18102	Thread Guide (on Needle Bar Frame) Screw
224028	16886	Thread Guide (on Top of Arm)
210592	18912	Thread Guide (upper)
200582X	18912	Thread Guide Screw (2)
202091	18102	Thread Retainer Sleeve
202092	18102	Thread Retainer Spring
204058	18102	Thread Retainer Stud
204059	18102	Thread Retainer complete, Nos. 202091, 202092 and 204058
200397X	18102	Thread Retainer Stud Set Screw
210600	16838	Throat Plate, 53 needle hole, for needle sizes 12 and 13
200577AL	16002	Throat Plate Screw (2)

ACCESSORIES

No.	Plate	Name
200157E	16895	Attachment Screw
263099	18908	Bobbin (2)
231337	16900	Cloth Guide
228212	15998	Drip Pan (short) with four 3/4 in. wire nails
41400	16900	Machine Rest Pin (wood)
131 x 1	-----	Needles, six, size 12
131 x 3	-----	Needles, six, size 12
120342	16900	Oiler (copper plated) with 120343
120343	16900	Oiler Spout (3-1/2 in. long)
225498	16900	Screw Driver (7-1/4 in. long)
228476	16900	Screw Driver (Bobbin Case)
10875	16900	Wrench
23535	16900	Wrench
225554	16900	Wrench (steel)

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)

FOR "V" BELT DRIVE

259428	17853	Brake (leather)
259429	17853	Brake Clamp
200113F	17853	Brake Clamp Screw
225453	17853	Frame with 202277 and 259660
225454	17853	Frame Hinge Pin
202277	17853	Frame Oil Packing (wick)
259660	17853	Frame Oil Well Washer
225455	17853	Frame Spring
225456	17853	Frame Spring Plunger
259461	17853	Pulley with 200380C
200380C	17853	Pulley Set Screw
225381	17853	Spindle
225444	17853	Stop Latch
200056E	17853	Stop Latch Screw
225458	17853	Stop Latch Thumb Lever

ACCESSORIES

No.	Plate	Name
225459	17853	Stop Latch Thumb Lever Hinge Stud
225459	17853	Stop Latch Thumb Lever Joint Stud
202478	17853	Stop Latch Trip Lever
200299X	17853	Stop Latch Trip Lever Hinge Screw
225461	17853	Tension Bracket with 201499X
200082D	17853	Tension Bracket Screw
228026	17853	Tension Bracket Screw Washer
2102	17853	Tension Disc
13710	17853	Tension Spring
201499X	17853	Tension Stud
201572X	17853	Tension Stud Thumb Nut
225462	17853	Bobbin Winder Tension Bracket complete, Nos. 13710, 201572X, 225461 and two 2102
259662	17853	Bobbin Winder and Tension Bracket Base
259462	17853	Universal Bobbin Winder complete, Nos. 200056E, 200082D, 200113F, 200299X, 202478, 225381, 225444, 225453 to 225456, 225458, 225462, 228026, 259428, 259429, 259461, 259662, two each 225459 and wood screws 3/4 in., No. 12, R. H. B.

Note: Bobbin Winder 259462 is furnished with this Machine unless Bobbin Winder 259431 is specified on order

KNEE LIFTER

228713	18580	Rock Lever with two 350231C
228707	18580	Rock Lever Bracket with 200347AL and three wood screws 7/8 in., No. 12
228709	18580	Rock Lever Bracket 228707 with 228363, 228367, 228386, 228455 and 228713
228370	18580	Rock Lever Extension with 200530C
350231C	18580	Rock Lever Extension Set Screw
228363	18580	Rock Lever Hinge Pin
228364	18580	Rock Lever Knee Plate with 350231C
228388	18580	Rock Lever Knee Plate Arm
350231C	18580	Rock Lever Knee Plate Arm Set Screw
350231C	18580	Rock Lever Knee Plate Set Screw
228455	18580	Rock Lever Position Spring
228365	18580	Rock Lever Rod
200530C	18580	Rock Lever Rod Set Screw
228386	18580	Rock Lever Spring
228367	18580	Rock Lever Stop Stud
200347AL	18580	Rock Lever Stop Stud Set Screw
228710	18580	Knee Lifter Rock Lever complete, Nos. 228364, 228365, 228370, 228388 and 228709

(Other Knee Lifter Parts are listed with parts of Machine Head.)

ACCESSORIES

THREAD UNWINDER

(FOR THREE SPOOLS)

No.	Plate	Name
228692	16257	Spool Pin
201528X	16257	Spool Pin Nut
228693	16257	Spool Pin Washer
225259	16257	Spool Rest (for one spool) (flat) with 201018C, 201528X, 228692 and 228693
225257	16257	Spool Rest (for two spools) (flat) with 201018C, two each 201528X, 228692 and 228693
150203	16257	Spool Rest Cushion (felt)
225388	16257	Spool Rest Rod
200383C	16257	Spool Rest Rod Set Screw
201018C	16257	Spool Rest Set Screw
259658	16257	Spool Stand with 200383C
225391	16257	Thread Guide
201696X	16257	Thread Guide Lock Nut
225326	16257	Thread Guide Position Cup
225324	16257	Thread Guide Rod with 208AL and 225322
208AL	16257	Thread Guide Rod Screw
225322	16257	Thread Guide Rod Washer
259143	16257	Thread Unwinder (for three spools) complete, Nos. 201696X, 225257, 225259, 225324, 225326, 225388, 259658, three each 150203, 225391 and wood screws 7/8 in., No. 12









MISCELLANEOUS PARTS

USED IN CONJUNCTION WITH THREAD UNWINDER

60913	16257	Spool Weight with 60914
60914	16257	Spool Weight Center Pin
225377	16257	Spool Wire (for small spools)
27739	16257	Thread Cone (wood)
225390	16257	Thread Cone Holder

FITTINGS

NEEDLE VIBRATOR CAMS

No.	Plate	Name	STITCH DESIGN
242205	18925	Needle Vibrator Cam (No. 5) (Arrowhead)	
242206	18925	Needle Vibrator Cam (No. 6) (Domino)	
242208	18925	Needle Vibrator Cam (No. 8) (Solid Scallop)	
242209	18925	Needle Vibrator Cam (No. 9) (Icicle)	
242210	18925	Needle Vibrator Cam (No. 10) (Banner)	
242211	18925	Needle Vibrator Cam (No. 11) (Key)	
242212	18925	Needle Vibrator Cam (No. 12) (Walls of Troy)	
242213	18925	Needle Vibrator Cam (No. 13) (Solid Diamond)	
242214	18925	Needle Vibrator Cam (No. 14) (Zigzag Point)	