

# HISTORICAL COPY

DEPARTMENT No. 54  
SEPTEMBER 8, 1928

## DO NOT REMOVE

### LIST OF PARTS COMPLETE

FOR

# MACHINE No. 149-4

FOR STITCHING CENTERS ON MEN'S SHIRTS AND OTHER WORK IN FABRICS REQUIRING FOUR-ROW STITCHING. FOUR NEEDLES AND FOUR LOOPERS. THE GREATEST DISTANCE BETWEEN THE OUTSIDE NEEDLES IS  $1\frac{1}{2}$  INCHES, WHICH CAN BE DIVIDED INTO SMALLER GAUGES BETWEEN EACH NEEDLE AS ORDERED, EXCEPT THAT NONE CAN BE MADE SMALLER THAN  $\frac{3}{16}$  INCH. SPEED UP TO 3400, ACCORDING TO THE MATERIAL BEING STITCHED.  
FORMERLY 149 S. V. 4 MACHINE

|         |  |
|---------|--|
| *128632 | Arm, upper and lower (solid).....  |
| 128502  | " Back Cover.....  |
| 190b    | " " " Screw.....   |
| 128502  | " Side Cover.....  |
| 286b    | " " " Thumb Screw.....   |
| 128503  | " Rotary Shaft.....  |
| 128613  | " " " 128503 with 50913c and 128559.....                                       |
| 128661  | " " " 128613 with 128663.....  |
| 128501  | " " " Ball Bearing.....  |
| 128505  | " " " " " Case.....  |
| 128627  | " " " " " " 128505 with<br>128501, 128506 and three 205F.....                  |
| 128506  | Arm Rotary Shaft Ball Bearing Case Cap with 128619                             |
| 128619  | " " " " " " " Pad (felt)   |
| 205F    | " " " " " " " Screw.....   |
| 30Sc    | " " " " " " " Set Screw ..   |
| 51007   | " " " Bushing (intermediate).....  |
| 54089   | " " " " " " 51007 with<br>64508 and 64805.....                                 |
| 64508   | Arm Rotary Shaft Bushing (intermediate) Oil Pad<br>(braided cotton) long.....  |
| 64805   | Arm Rotary Shaft Bushing (intermediate) Oil Pad<br>(braided cotton) short..... |
| 88Sc    | Arm Rotary Shaft Bushing (intermediate) Set Screw ..                           |
| 128507  | " " " " " (front).....   |
| 50999c  | " " " " " " Set Screw ..   |
| 128508  | " " " Collar with two 125Sc.....   |
| 125Sc   | " " " " " Set Screw.....   |
| 19013   | " " " Front Bearing Oil Pad (braided<br>cotton).....                           |

|        |   |       |
|--------|---|-------|
| 128509 | Balance Wheel, 2 in. pulley, with two 430c  | ..... |
| 128510 | “ “ “ Cover   | ..... |
| 14R    | “ “ “ “ Screw   | ..... |
| 430c   | “ “ “ “ Set Screw   | ..... |
| 128633 | Cloth Plate   | ..... |
| 128513 | “ “ Oil Tube with 49092, for oiling 128520  | ..... |
| 49092  | “ “ “ “ Packing (felt)  | ..... |
| 128514 | “ “ Slide   | ..... |
| 38416  | “ “ “ Spring  | ..... |
| 725J   | “ “ “ “ Screw   | ..... |
| 128515 | Cloth Plate Slide complete, Nos. 128514, two 38416 and four 725J                    | ..... |
| 128634 | Cloth Plate complete, Nos. 128513, 128515, 128633 and two 1198c                     | ..... |
| 1011F  | Cloth Plate Screw (left)  | ..... |
| 50473F | “ “ “ (right)   | ..... |
| 128635 | Feed Bar with two 453c  | ..... |
| 128636 | “ “ 128635 with 128519 and two 190b   | ..... |
| 128707 | “ “ 128636 with 57225 and 128533  | ..... |
| 57225  | “ “ Hinge Pin   | ..... |
| 453c   | “ “ “ “ Set Screw   | ..... |
| 42366  | “ “ Oil Pad (braided cotton)  | ..... |
| 128518 | “ “ Wearing Block   | ..... |
| 128519 | “ “ “ Plate   | ..... |
| 190b   | “ “ “ “ Screw   | ..... |
| 128520 | “ Connection (forked) with 453c and 769c  | ..... |
| 128615 | “ “ 128520 with 1095e, 128522, 128528, 128532 and two 128521                        | ..... |
| 769c   | Feed Connection Clamping Screw  | ..... |
| 453c   | “ “ Set Screw   | ..... |
| 128521 | “ “ Slide Block Section   | ..... |
| 128522 | “ “ “ “ Sleeve  | ..... |
| 1095F  | “ “ “ “ Cap Screw   | ..... |
| 128738 | “ Dog, 19 teeth (16 teeth to the inch) with 452c                                    | ..... |
| 452c   | “ “ Adjusting Screw   | ..... |
| 157b   | “ “ Screw   | ..... |
| 128638 | “ Lifting Eccentric with two 452c   | ..... |
| 452c   | “ “ “ Set Screw   | ..... |
| 50941c | “ Regulating Screw  | ..... |
| 128526 | “ “ “ Plate   | ..... |
| 391b   | “ “ “ “ Screw   | ..... |
| 128527 | “ Regulator with two 1143c  | ..... |
| 128528 | Feed Regulator complete, Nos. 391b, 399b, 50941c, 128526, 128527, 128530 and 128531 | ..... |
| 128529 | Feed Regulator Bushing  | ..... |
| 50999b | “ “ “ Set Screw   | ..... |
| 41036  | “ “ Oil Pad (felt)  | ..... |
| 1143c  | “ “ Set Screw   | ..... |

|         |  |       |
|---------|--|-------|
| 128530  | Feed Regulator Slide Block   | ..... |
| 128531  | “ “ “ “ Stop   | ..... |
| 399b    | “ “ “ “ “ Screw  | ..... |
| 128532  | “ “ “ “ Washer   | ..... |
| 128533  | “ Rocking Frame with two each 453c and 1324c                                     | ..... |
| 1324c   | “ “ “ Adjusting Screw  | ..... |
| 128534  | “ “ “ Hinge Pin  | ..... |
| 57235   | “ “ “ “ “ Bushing  | ..... |
| 453c    | “ “ “ “ “ “ Set Screw  | ..... |
| 453c    | “ “ “ “ “ “ Set Screw  | ..... |
| 128768  | Looper (self threading) with 590b, 61041 and 128702                              | ..... |
| 128739  | “ Carrier with four 50379e   | ..... |
| 128769  | “ “ 128739 with 228b and 128740  | ..... |
| 128537  | “ “ Driver   | ..... |
| *128538 | “ “ “ Connection   | ..... |
| 128630  | “ “ “ “ 128538 with two 128539 and four 896e                                     | ..... |
| 128621  | Looper Carrier Driver Connection complete, Nos. 128630, 128631 and two 142e      | ..... |
| 128663  | Looper Carrier Driver Connection 128621 with 128537, 128543 to 128547 and 128641 | ..... |
| *128539 | Looper Carrier Driver Connection Cap   | ..... |
| 896e    | “ “ “ “ “ Screw  | ..... |
| *128540 | “ “ “ “ “ End Bearing  | ..... |
| 128631  | “ “ “ “ “ “ 128540 with 128541   | ..... |
| *128541 | Looper Carrier Driver Connection End Bearing Cap                                 | ..... |
| 142e    | “ “ “ “ “ “ “ “ Screw  | ..... |
| 128641  | Looper Carrier Driver Eccentric with 791c and two 452c                           | ..... |
| 791c    | Looper Carrier Driver Eccentric Position Screw                                   | ..... |
| 452c    | “ “ “ “ “ Set Screw  | ..... |
| 128543  | “ “ Holder with two 896e   | ..... |
| 896e    | “ “ “ Clamping Screw   | ..... |
| 128544  | “ “ Rock Shaft   | ..... |
| 128545  | “ “ “ Hinge Pin  | ..... |
| 413c    | “ “ “ “ “ “ Set Screw  | ..... |
| 128546  | “ “ “ “ Nut  | ..... |
| 128547  | “ “ “ “ “ Clamp with 175b  | ..... |
| 175b    | “ “ “ “ “ “ Screw  | ..... |
| 898c    | “ “ “ Screw  | ..... |
| 128642  | “ Eccentric with two 889c  | ..... |
| 128635  | “ “ 128642 with 1664e, 50942e, 128549, 128624 and two 55515                      | ..... |
| 55515   | Looper Eccentric Oil Pad (braided cotton)  | ..... |
| 889c    | “ “ Set Screw  | ..... |
| 128549  | “ “ Sleeve   | ..... |

|  |   |
|--|---|
| 128550   | Looper Eccentric Sleeve Connection with 128552 and two 175E                 |
| 128624   | Looper Eccentric Sleeve Connection 128550 with 679c                         |
| 679c   | “ “ “ “ Ball Screw Stud   |
| 1520J  | “ “ “ “ “ “ “   |
|  | Nut   |
| 128551   | Looper Eccentric Sleeve Connection Ball Screw Stud Nut Lock Washer          |
| *128552  | Looper Eccentric Sleeve Connection Cap                                      |
| 175E   | “ “ “ “ “ Screw   |
| 50942c   | “ “ “ “ “ Hinge Screw   |
| 1664E  | “ “ “ “ “ “ Nut   |
| 50379F   | “ Set Screw   |
| 128702   | “ Thread Guard  |
| 61041  | “ “ “ Pin   |
| 590D   | “ “ “ Screw   |
| <b>128740</b>  | “ “ Guide   |
| NOTE: When ordering No. 128740, state gauge required |   |
| 228D   | Looper Thread Guide Screw   |
| 57244  | Needle Bar (hollow)   |
| 61181  | “ “ 57244 with 61094  |
| 38456  | “ “ Bushing (lower)   |
| 1133E  | “ “ “ “ Set Screw   |
| 128554   | “ “ “ (upper)   |
| 1133E  | “ “ “ “ Set Screw   |
| 128555   | “ “ Connecting Bracket with 1057D, 50370D and 50379F                        |
| 128713   | Needle Bar Connecting Bracket 128555 with 128556 and 128557                 |
| 1057D  | Needle Bar Connecting Bracket Clamping Screw                                |
| 128556   | “ “ “ “ Link  |
| 128557   | “ “ “ “ Hinge Pin   |
| 50370D   | “ “ “ “ “ “ Set Screw   |
| 128558   | “ “ Lever with 50282E, 50370D and two 1259c                                 |
| 128618   | “ “ “ 128558 with 128557 and 128713   |
| 50943c   | “ “ “ Ball Screw Stud   |
| 1259c  | “ “ “ “ “ “ Set Screw   |
| 128559   | “ “ “ Connecting Rod with 683E, 54897, 128560, 128561, 128628 and four 896E |
| *128560  | Needle Bar Lever Connecting Rod Cap (lower)                                 |
| 896E   | “ “ “ “ “ “ “ Screw   |
| *128561  | “ “ “ “ “ “ (upper)   |
| 896E   | “ “ “ “ “ “ “ Screw   |
| 42077  | “ “ “ “ “ Guide   |
| 171E   | “ “ “ “ “ “ Screw   |
| 54897  | “ “ “ “ “ Oil Cup   |

|               |  |
|---------------|--|
| 128628        | Needle Bar Lever Connecting Rod Oil Pad (braided cotton)                                 |
| 683E          | Needle Bar Lever Connecting Rod Oil Pad Stop Screw                                       |
| 128562        | “ “ “ Hinge Pin  |
| 128563        | “ “ “ “ “ Bushing (back)   |
| 443c          | “ “ “ “ “ “ “ Set Screw  |
| 128564        | “ “ “ “ “ “ (front)  |
| 743c          | “ “ “ “ “ “ “ Set Screw  |
| 54648         | “ “ “ “ “ “ “ Oil Pad (braided cotton)   |
| 50282E        | Needle Bar Lever Set Screw   |
| 61094         | “ Clamp with four 50014E   |
| 50014E        | “ Set Screw  |
| 128567        | Oil Cup  |
| 128568        | Oil Cup complete, for oiling 128550, Nos. 128567 and 128569 to 128571                    |
| 128569        | Oil Cup Pad (felt)   |
| 792c          | “ “ Screw  |
| 128570        | “ “ Tube   |
| 128571        | “ “ “ Wick (braided cotton)  |
| 128572        | “ Cup  |
| 128573        | Oil Cup complete, for oiling 128538, Nos. 11006, 128572, 128574 to 128576 and two 128571 |
| 128574        | Oil Cup Bracket  |
| 41006         | “ “ Pad (felt)   |
| 1239F         | “ “ Screw  |
| 128575        | “ “ Tube (long)  |
| 128576        | “ “ “ (short)  |
| 128574        | “ “ “ Wick (braided cotton)  |
| 128577        | “ Tube   |
| 49092         | “ “ Packing (felt)   |
| <b>128741</b> | “ “ Bracket and Thread Guide with 49092 and 128577                                       |
| 61477         | Presser Bar with 25303   |
| 25303         | “ “ Ball, size 1/4 in.   |
| 61046         | “ “ Bushing (lower)  |
| 1133E         | “ “ “ “ “ Set Screw  |
| 38456         | “ “ “ (upper)  |
| 1133E         | “ “ “ “ “ Set Screw  |
| 128580        | “ “ Guide Bracket with 175c and 454c   |
| 175c          | “ “ “ “ “ Adjusting Screw  |
| 128581        | “ “ “ “ “ Guide  |
| 457c          | “ “ “ “ “ “ Set Screw  |
| 454c          | “ “ “ “ “ “ Set Screw  |
| 128582        | “ “ Lifter   |
| 57258         | “ “ “ Hinge Stud   |
| 443c          | “ “ “ “ “ “ Set Screw  |
| 51871         | “ “ “ Roller and Stud  |