

LIST OF PARTS
MACHINE NO. 107W53

*210501 Arm with 202135
 203087 " Cap
 200278X " " Screw
 202248 " " " Washer
 203089 " " Spool Holder Base
 203090 " " " " " 203089 with 200079X and 204296
 200585X " " " " " Screw
 204296 " " " " " Wire
 200079X " " " " " Hinge Screw
 203088 Arm Cap and Spool Holder complete, Nos. 203087, 203090, and two 200585X

 204235 " Position Pin (2)
 200010E " Screw (3)
 202005 " " Washer (3)
 202249 " Shaft with 224392
 240802 " " Bushing (back) with 202244
 202244 " " " " Oil Packing (wick)
 200338C " " " " Set Screw
 207080 " " " (front) with 202244
 202244 " " " " Oil Packing (wick)
 200502X " " " " " " Thumb Screw
 200341C " " " " Set Screw
 224400 " " Connection Belt (reinforced neoprene)
 202635 " " " " Pulley with 200327C, 200602C, and two 202253
 200602C " " " " Pulley Position Screw
 200327C " " " " " Set Screw
 202253 " " " " " Spring Flange
 224392 " " Oil Packing (wick)
 *242001 Bed (cylinder)

MACHINE NO. 107w53

213890 Bed Base (4 inches high)
NOTE: Bed Base 213890 is furnished with this machine unless
otherwise specified on order

213353 Bed Base (6 inches high)

203184 " Clamp

200262X " " Hinge Screw

202622 " " Packing Washer

200728X " " Thumb Screw

203185 " " " " Washer

202618 " Hinge

201110X " " Screw (6)

210505 " Plate (back)

200577AL " " " Screw (2)

263099 Bobbin

210846 " Case Base

224440 " " Cap with 200592C, 201016C and 263110

224441 Bobbin Case Cap complete, Nos. 200964C, 210736, 210914 and 224440

210913 " " Latch

210914 " " " 210913 with 210734 and 210735

210735 " " " Fulcrum Pin

210734 " " " Lever

210736 " " " Spring

200964C " " " Stop Screw

242002 " " Stop

200126D " " " Screw

263110 " " Tension Spring

201016C " " " " Regulating Screw

200592C " " " " Screw

224442 Bobbin Case complete, Nos. 210846 and 224441

MACHINE NO. 107*53

242003 Cylinder End Cover with 242004 and two 200177D
200294X " " " Hinge Screw (2)
242004 " " " Latch
200177D " " " " Screw
210681 Face Plate
202135 " " Position Pin
200462X " " Thumb Screw
210682 Face Plate complete, Nos. 210681, 210684 and two 200137X
— 242005 Feed Bar
242006 " " 242005 with 200641C, 201522E and 202623
200641C " " Hinge Screw (driving)
201522E " " " " Nut
- 202276 " " Slide Block
202624 " " " " Crank with 200038C
— 242008 " " " " " 202624 with 200205F, 201518E and 202276
200038C " " " " " Pinch Screw
200205F " " " " " Hinge Screw
201518E " " " " " " Nut
242018 " Dog, for 210603
200106E " " Screw (2)
202297 " Driving Connection with 200054E and 203101
242022 " " " Crank with 200038C
200038C " " " " Pinch Screw
200545C " " " " Hinge Screw
201518E " " " " " Nut
203101 " " " " Oil Packing (wick)
200054E " " " " Pinch Screw
202300 " " Eccentric Regulating Bracket

MACHINE NO. 107453

203098	Feed Driving Eccentric	Regulating Bracket	202300 with 202635, two each 201014C and 201525E
201014C	"	"	Regulating Bracket Hinge Screw
201525E	"	"	" " " Nut
202301	"	"	" " Plunger
202595	"	"	" " Spring
200607C	"	"	" " Stop Screw
201014C	"	"	Regulating Bracket Stop Screw
201525E	"	"	" " " Nut
200429F	"	"	" " Screw
200383C	"	"	" " Check Screw
202623	"	"	Rock Shaft
202625	"	"	" " Stop Collar with two 200383C (2)
200383C	"	"	" " " Set Screw
202306	"	"	Lifting Connection with 200054E and 203101
*210645	"	"	" Crank
210589	"	"	" " 210645 with 200050C and 200378C
200050C	"	"	" " Pinch Screw
200378C	"	"	" " Set Screw
202307	"	"	" " Eccentric with 200382ALX and 200437C
200437C	"	"	" " Position Screw
200382ALX	"	"	" " Set Screw
200545C	"	"	" " Hinge Screw
201518E	"	"	" " " Nut
203101	"	"	" " Oil Packing (wick)
200054E	"	"	" " Pinch Screw
210531	"	"	Rock Shaft (hollow) and Hook Driving Shaft Bear- ing
202625	"	"	" " Stop Collar with two 200383C

MACHINE NO. 107W53

200333C Food Lifting Rock Shaft Stop Collar Set Screw
200310 " Regulating Spindle with 202311, 202443 and 202619
*202311 " " " Head
202443 " " " " Pin
202619 " " " " Position Pin
224432 Hook (sewing) with 203101 and ~~263134~~ 502535
224433 " 224432 with 2001L50, 210536, 210541 and three 200596F
224443 Hook and Bobbin Case complete, Nos. 224433 and 224442
210614 " Driving Bevel Pinion (steel), 24 teeth, with two 200378C
200378C " " " " Set Screw
210535 " " " " Shaft
202661 " " " " " Belt Pulley with 202324 and
two 200378C
200378C " " " " " Shaft Belt Pulley Set Screw
202324 " " " " " " " Spring Flange
210536 " Gib
200596F " " Screw
535-~~263134~~ " Oiling Felt
203101 " Oil Wick
350984F " Position Screw
242011 " Shaft (hollow)
210615 " " Bevel Gear (steel), 24 teeth, with two 200382ALX
200382ALX " " " " Set Screw
242020 " " Bushing with 265683
242012 " " " 242020 with 200931F and 242011
265683 " " " Oil Packing (wick)
0363AL-~~201007C~~ " " " Set Screw
244084 " " " " " packing (fibre)
200931F " " Position Screw

MACHINE NO. 107W53

210541	Hook Washer	Needle Guard
2001450	"	" " " " Screw
242009	Knee Lifter	Lifting Lever
200242X	"	" " " " Hinge Screw
242010	"	" " " " Rod with 202302
202302	"	" " " " Cotter Pin
233361	"	" " " " Spring
200273D	"	" " " " Screw
233390	"	" " " " Washer
244090	Machine Pulley (disc)	(aluminum alloy casting) "V" belt groove (outside diam. of belt groove 2.9 in.) with 3505406 and 3505410 <i>141566C</i> <i>141567C</i>
440 3505406	"	" " Position Screw
507C 3505410	"	" " Set Screw
224317	Needle Bar with 200125ALX, 200175X and 249270	
210543	"	" " Connecting Link
202333	"	" " " " Stud with 202299
202299	"	" " " " Oil Packing (wick)
200383C	"	" " " " Set Screw
200374AL	"	" " " " " " "
210544	"	" " " " Stud with 202299
210585	"	" " " " 210544 with 210882
202299	"	" " " " Oil Packing (wick)
210882	"	" " " " Swivel with 200387C
210725	"	" " Crank with 200335C, 200374AL, 200383C, ^{200432C} 200428C and 202333
203172	"	" " " " Friction Washer
0432C 200428C	"	" " " " Position Screw
200335C	"	" " " " Set Screw
200388C	"	" " " " LOCK SCREW <i>20</i>

202343	Presser Bar Spring
202346	" " " Stop Rod
200492X	" " Thumb Screw (pressure regulating)
200475X	" " " " Thumb Set Screw
244084	" " " " " " " Packing (fibre)
242053	" Foot Edge Guide
200175X	" " " " Screw
230795	" " Hinge Pin
242054	" " Plate
200074F	" " Screw
202923	" " Shank
242055	Presser Foot (hinged) complete, Nos. 200175X, 202923, 230795, 242053 and 242054
210591	Take-up (auxiliary), for Swivel
200132E	" " Screw
244059	" Lever
202399	" " Driving Stud with 244071
244071	" " " " Oil Packing (wick)
202400	" " Hinge Stud with 202423
202423	" " " " Oil Packing (wick)
200383C	" " " " Set Screw
202401	" " Oiling Felt
200132E	" " " " Screw
244048	Tension Disc (back)
244049	" " (front)
202404	" Release Plunger
244061	" " Washer
223438	" Spring
263106	" " Washer

MACHINE NO. 107w53

200625F Tension Stud with 204925
200061ALX " " Set Screw
204925 " " Washer
201572X " Thumb Nut
244662 Tension complete, Nos. 200625F, 201572X, 202410, 223438, 244048,
244049, 244061 and 263106
202410 Thread Controller Spring
241443 " " " Stop
200132E " " " " Screw
210593 " Guide (lower)
202412 " " (on top of Arm)
210592 " " (upper)
200582X " " Screw (2)
240335 " Retainer
210683 " " Bracket with 200397X
200137X " " " Screw
200368X " " Set Screw
210993 " " Sleeve
210992 " " Spring
210957 " " Stud
210958 " " " Collar
200397X " " " Set Screw
210684 Thread Retainer Bracket complete, Nos. 210683, 210957, 210958,
210992 and 210993
210693 Throat Plate, 53 needle hole, for needle sizes 12 and 13, for
242018
200577AL " " Screw (2)

ACCESSORIES

200157X	Attachment Screw
263099	Bobbin (2)
259462	Bobbin Winder
203058	Knee Lifter Lifting Lever Rock Coupling
228251	Knee Lifter Rock Shaft complete
51078	Machine Bolt (4)
6055	Machine Bolt Washer (4)
41401	Machine Rest Pin
135x5	Needles #14 (6)
120342	Oil Can
225498	Screw Driver
228476	Screw Driver (Bobbin Case)
242017	Work Plate
201011X	Work Plate Screw (back)
200577AL	Work Plate Screw (front)(2)
225554	Wrench