

Singer 69-14

**LIST OF PARTS
COMPLETE**



NO. 69-14 MACHINE

The Singer Manufacturing Co.

LIST OF PARTS COMPLETE
FOR
No. 69-14 Machine

Central Bobbin, makes 18 staying and three fastening or
 tying stitches in two parallel lines, makes tack from
 $\frac{7}{32}$ in. to $\frac{7}{16}$ in. long. For tacking Blucher
 Shoes. (Formerly 69 S.V. 3 Machine)

18460	Arch Clamp Foot (left) with 17959.....
18461	" " " (right) " 17959.....
17958	" " " Lifter " 17866.....
190D	" " " " Screw.....
17959	" " " Lifting Stud.....
18433	" " " Plate.....
217	" " " " Screw.....
39302	" " " Spring.....
18434	" " " " Connection.....
1175D	" " " " " Hinge Screw....
217	" " " " " Screw.....
18435	" " " Frame.....
14079	" " " Dowel Pin.....
181D	" " " " Screw.....
18462	Arch Clamp complete, Nos. 1654C, 18367, 18433 to 18435, 18438, 18460, 18461, 18463, 39302, two each 181D, 1175D, 14079 and five 217.....
*18439	Arm with 4449, 17844 and two 164E.....
2002	" Dowel Pin.....
4448	" Oil Tube for intermediate bearing.....
880	" Screw.....
17702	" Shaft.....
17703	" " Bushing (back).....
435C	" " " " Adjusting Screw.....
1520E	" " " " " Nut....
*4449	" " " (front).....
23373	Belt Cover.....
39290	" " Bracket with 184E and 17741.....
184E	" " " Screw Stud.....
17741	" " " Stud.....
217D	" " " Screw.....

39222	Belt Shifter.....
39223	" " Clamp.....
1255D	" " " Screw.....
4292	Crank Connecting Rod.....
*4349	" " " Cap.....
158E	" " " " Screw.....
375C	" " " " Hinge Screw.....
1518E	" " " " " Nut.....
*18352	Cylinder.....
18388	" Block.....
1300D	" " Screw.....
18427	" End Cover with 18428, 18444 and three 4604.....
18428	Cylinder End Cover Bracket.....
18444	" " " " Hinge Pin.....
4604	" " " " Rivet.....
18379	" " " Spring.....
217D	" " " " Screw.....
17724	Face Plate.....
17725	Face Plate complete, Nos. 448C, 600, 1560C, 2103, 2105, 2107, 2124, 2127, 17724 and two each 233D and 2102.....
164	Face Plate Screw.....
2107	" " Thread Guard.....
233D	" " " " Screw.....
18353	Feed Across Connection.....
*18354	" " " Cap.....
175E	" " " " Screw.....
18355	" " " Knuckle Joint.....
1184C	" " " Hinge Screw.....
18356	" " " Regulator with 1952.....
1187D	" " " Adjusting Stud.....
1676	" " " " " Nut.....
17738	" " " " " Washer.....
17739	" " " " " Sleeve.....
18357	" " " Hinge Stud.....
690D	" " " " Clamping Screw.....
1952	" " " Roller and Stud.....
18358	" " " Shaft.....
18359	" " " Collar with two 200C.....
200C	" " " " Set Screw.....
18360	" " " Crank (back) with 160E and 200C.....
18361	" " " " " Ball Stud.....
200C	" " " " " Set Screw.....
160E	" " " " " Clamping Screw.....
18362	" " " " (front) with 160E and 18363.....

160E	Feed Across Shaft Crank (front) Clamping Screw.....
18363	" " " " " Stud.....
18364	" " " " " Slide Block.....
18404	Feed Cam with 1192C and two each 190D and 17874.....
18415	" " " Driving Worm with 1441C and 1442C.....
1442C	" " " " Position Screw.....
1441C	" " " " Set Screw.....
17797	" " " " Wheel with 453C.....
3012	" " " " " Pin.....
453C	" " " " " Set Screw.....
18384	" " " Pin.....
1192C	" " " Set Screw.....
18416	" " " Shaft.....
18417	" " " Bracket.....
1177D	" " " " Screw (back).....
1193D	" " " " (front).....
1653C	" " " Nut.....
18463	" Plate.....
18437	" " Carrier Bar.....
18438	" " " 18437 with 934D, 1195E, 1221, 17743, 18366, 18390, two 7476 and four 17806.....
18366	Feed Plate Carrier Bar Block.....
18367	" " " " " Cover.....
1221	" " " " " Screw.....
7476	" " " " " Steady Pin.....
17805	" " " " " Pivot Block.....
1194D	" " " " " Screw.....
18390	" " " " " Plate.....
934D	" " " " " Screw.....
1654C	" " " Nut.....
17806	" " " Position Stud.....
1195E	" " " Screw Stud.....
17742	" " Regulator with 1953.....
18369	" " Bracket with 690D, 17732 and two 160D.....
*17732	Feed Regulator Bracket Cap.....
160D	" " " " " Screw.....
8589	" " " " Dowel Pin.....
1177E	" " " " Screw.....
17744	" " " Hinge Stud.....
17743	" " " Post.....
1953	" " " Roller and Screw Stud with 1655C and 14017.....
1655C	Feed Regulator Roller and Screw Stud Nut.....
14017	" " " " " Washer.....
1190C	" " " Stop Screw.....
17745	" " " Swivel.....
1191D	" " " Thumb Screw.....

18389	Knife (needle thread)	
17808	" (shuttle thread)	
18370	" Bar with 18373 and two 17822	
18371	" " Cap	
217	" " " Screw	
18372	" " Connection with 17917	
190D	" " " Screw	
7071	" " " Washer	
17915	" " " Slide Block	
17916	" " " " Stud	
17917	" " " " 17915 with 17916	
39297	" " Driving Lever with 190D, 1420E, 17919 and 39298	
1882D	Knife Bar Driving Lever Hinge Screw	
1681C	" " " " Nut	
39298	" " " " Lock Stud	
17919	" " " " " Spring	
190D	" " " " " Screw	
1420E	" " " " " Stop Screw	
18373	" " Rack	
17822	" " " Rivet	
39235	" Cam Lever Body	
39237	Knife Cam Lever complete, Nos. 1174, 19793, 39235 and 39236	
18375	Knife Cam Lever Bracket	
8539	" " " " Dowel Pin	
670E	" " " " Screw	
1197D	" " " " Hinge Screw	
1964	" " " " Roller and Stud	
39236	" " " " Slide with 1964	
1174	" " " " Screw	
19793	" " " " Steady Pin	
17825	" Holder with 17826, 17830 and two 7298	
17826	" " " Pinion	
8539	" " " Dowel Pin	
17827	" " " Stud	
17828	" " " " Bracket with 17827	
1319	" " " " Screw	
1198D	" Screw	
17829	" Thread Holder	
17830	" " " Position Pin	
17831	Needle Bar with 237	
39203	" " Connecting Link	
377C	" " " " Hinge Screw	
1518E	" " " " Nut	
2052	" " " " Stud with 155C	
155C	" " " " Set Screw	

17832	Needle Bar Thread Nipper Driving Lever	
1196C	" " " " " " Hinge Screw	
17833	Needle Bar Thread Nipper Driving Lever Spring	
17834	" " " " Lever with 17835	
17835	" " " " Bushing	
1200D	" " " " Hinge Screw	
39276	" " " " Spring	
1329	" " " " " Screw	
17837	" " " " Rod	
17838	" " " " Adjusting Stud	
1651E	" " " " " Lock Nut	
17839	Needle Bar Thread Nipper Rod Arm with 196	
196	" " " " " Set Screw	
17840	" " " " " Support	
190D	" " " " " Screw	
237	" Set Screw	
6022	Oscillating Rock Shaft (steel) with 4784	
6489	" " " Hinge Pin	
1513C	" " " " Nut	
4784	" " " Oil Pad	
18385	" Shaft	
18386	" Crank	
18387	Oscillating Shaft Crank complete, Nos. 237, 1519E, 15171 and 18386	
2049	Oscillating Shaft Crank Pin	
237	" " " Set Screw	
15170	" " " Slide Block	
229D	" " " " Cap Screw	
12424	" " " " Washer	
1035C	Oscillating Shaft Crank Slide Block Screw Stud	
1519E	" " " " " Nut	
15171	Oscillating Shaft Crank Slide Block complete, Nos. 229D, 1035C, 12424 and 15170	
2058	Presser Bar	
17841	" " Collar with two 196	
196	" " " Set Screw	
17842	" " Guide Bracket with 453C	
453C	" " " Set Screw	
17843	" " Lifting Lever	
17844	" " " Bracket	
164E	" " " " Screw	
1201D	" " " " Hinge Screw	
17845	" " " " Rod	
17846	" " " " Chain	
8414	" " Spring	

17941	Pulley (loose) 3 in. diam.....
17848	" " Bushing.....
2269	" " " Position Pin.....
1202D	" " Cap Screw.....
17942	" (tight) 3 in. diam., with 2269.....
2022	" " Pin.....
17955	Pulleys complete, Nos. 1202D, 1206C, 17848, 17854, 17941 and 17942.....
2996	Shuttle Bobbin.....
15140	" " Case Latch.....
2973	" " " Lever.....
2974	" " " Fulcrum Pin.....
2975	" " " Spring.....
592E	" " " Stop Screw.....
15141	" " Hinge, Nos. 2973, 2974 and 15140.....
15027	Shuttle Bobbin Case Position Finger.....
2523	" " " Rivet.....
15142	Shuttle Bobbin Case complete, Nos. 591, 592E, 2523, 2975, 15027, 15098 and 15141.....
21562	Shuttle Body.....
591	" Tension Regulating Screw.....
15098	" Spring.....
21561	Shuttle, 1 $\frac{1}{16}$ in. diam., Nos. 2996, 15142 and 21562..
*2542	" Driver.....
2441	" " 2542 with two 462C.....
2049	" " Pin.....
462C	" " Set Screw.....
18411	" Race Body.....
21623	" " Cap.....
662D	" " Screw.....
2523	" " Steady Pin.....
18429	" " Ring.....
18413	" " Spring.....
1289D	" " Screw.....
18430	Shuttle Race (flexible) complete, Nos. 662D, 2523, 18411, 18429, 21623 and two each 1289D and 18413.....
171	Shuttle Race Screw.....
17853	Starting Lever.....
1262c	" " Hinge Screw.....
1662c	" " " Nut.....
17886	" " Pitman.....
17854	Stop Cam.....
17855	" " Interlocking Rod.....
18440	" " " Case with 18443 and two 193.....
18441	Stop Cam Interlocking Rod Case Bracket.....

18442	Stop Cam Interlocking Rod Case Bracket complete. Nos. 1182E, 1196C, 1204E, 1254C, 1262C, 1318D, 1508C, 1662C, 17853, 17855, 17859 to 17864, 17872, 17873, 18440, 18441, 39222, 39223 and two each 898D and 1255D.....
16532	Stop Cam Interlocking Rod Case Bracket Dowel Pin.....
1343E	Stop Cam Interlocking Rod Case Bracket Screw.....
1204E	" " " " Hinge Screw.....
17859	" " " " Socket Joint.....
898D	" " " " " Cap Screw.....
17860	Stop Cam Interlocking Rod Case Spring.....
17861	" " " " Stop Stud.....
1254c	" " " " " Screw Bushings.....
1508c	Stop Cam Interlocking Rod Case Stop Stud Screw Bushings Lock Nut.....
17862	Stop Cam Interlocking Rod Case Stop Stud Spring..
18443	" " " " Wearing Block
193	" " " " " " "
17863	Stop Cam Interlocking Rod Spring.....
17864	" " " " Stop.....
1818D	" " " " Screw.....
3012	" " Pin.....
1206c	" " Screw.....
2102	Tension Disc.....
1560c	" Regulating Thumb Nut.....
600	" Screw Stud.....
448c	" " Set Screw.....
2103	" Spring.....
2105	" Thread Guard.....
17748	Thread Eyelet (top of arm).....
18392	" Take-up Cam with 446c.....
3012	" " Pin.....
446c	" " Set Screw.....
18393	" " Lever with 1822.....
79c	" " Hinge Screw.....
1822	" " Roller and Stud.....
2124	" " Spring.....
2127	" " Regulator Plate.....
233D	" " " Adjusting Screw.....
17865	Thread Wiper Body.....
1207D	" " Hinge Screw.....
17866	" " Hook.....
17867	" " Support.....

641	Thread Wiper Body Support Set Screw
17868	" " " Wire
337D	" " " " Screw
17869	" " " " Washer
18381	Throat Plate with 17871 and two 1208D
17871	" " Needle Hole Bushing
1208D	" " " " " Screw
691	" " " " " Screw
17872	Trip Lever
1196C	" " Hinge Screw
17873	" " Spring
1182E	" " " " " Screw
17874	Tripping Point
190D	" " " " " Screw

ATTACHMENTS AND ACCESSORIES

18419	Cylinder Base Plate
18420	" " " Hinge Connection
18423	" " " " " Hinge Pin
453C	" " " " " " " "
	Set Screw
18424	Cylinder Base Plate (hinged) complete, Nos. 18419, two each 453C, 18420, 18423, three wood screws 1 1/4 in. No. 12 and four 134D
134D	Cylinder Base Plate Screw
26420	Oiler with Cap and 26422
26421	" 26420 filled with oil
26422	" Spout, 3 1/2 in. long
26026	Screw Driver (machine)
26485	" " (shuttle tension)
10875	Wrench for 1518 and 1520
27662	" " 1508
17905	" " 1178, 1267, 1654 and 1676
22008	" " 1651

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)

27540	Base
15072	Bobbin Position Pin
27302	Frame
32D	" Hinge Screw
27303	" Spring
27541	Pulley

27538	Spindle with 15072
27306	Spool Pin
27307	" Stand
27308	Spool Stand complete, Nos. 418D, 1562D, 2106, 10141, 11241, 27306, 27307, wood screw 1 in. No. 10 and two 2455
11241	Spool Washer (cloth)
27312	Stop Latch
35D	" " Hinge Screw
2455	Tension Disc
1562D	" Regulating Thumb Nut
418D	" Screw Stud
10141	" Spring
2106	" Thread Guide
27647	Bobbin Winder, Nos. 32D, 35D, 27302, 27303, 27312, 27538, 27540, 27541 and two wood screws 1 in. No. 7
27544	Bobbin Winder complete, Nos. 27308 and 27647

BOBBIN WINDER

SWINGING AUTOMATIC, RIGHT HAND (HAMBURG)

This Bobbin Winder is the same as 27544 with the following exceptions:

27610	Spindle with 15072, in place of 27538
2846	" for Spool
27611	" 27610 with 2846
27656	Bobbin Winder, Nos. 32D, 35D, 27302, 27303, 27312, 27540, 27541, 27611 and two wood screws 1 in. No. 7
27612	Bobbin Winder complete, Nos. 27308 and 27656

STARTING LEVER AND FOOT LIFTER PARTS

17876	Treadle
17877	" Pitman Rod (lower)
17878	" " " (upper)
17879	" " " Clamp with two 161D
161D	" " " " " Screw

17880	Treadle Pitman complete, Nos. 17877 to 17879.....
17881	“ Shaft.....
186	“ “ Set Screw.....
17882	“ Spring.....
17883	“ Stand.....
17884	Treadle complete, Nos. 186, 17876, 17881 to 17883 and two wood screws 1 in. No. 10.....
17885	Treadle and Pitman complete, Nos. 17880 and 17884

TABLE BELT GUIDE

39218	Belt Guide with two 168E.....
168E	“ “ Set Screw.....
17892	Bracket with two 153E.....
17893	Pulley.....
39219	“ Shaft (long) with 17896.....
39220	“ “ (short) “ “.....
17896	“ “ Plug.....
153E	“ “ Set Screw.....
39221	Table Belt Guide complete, Nos. 17892, 39219, 39220, two each 17893, 39218 and three wood screws 1¼ in. No. 12.....

THREAD UNWINDER

FOR TWO LARGE SPOOLS

27936	Spool Pin.....
27937	“ Rest.....
27938	“ “ 27937 with two each 453c and 27936.....
27939	“ “ Rod.....
453c	“ “ “ Set Screw.....
453c	“ “ Set Screw.....
27940	“ Stand with 453c.....
27941	“ Washer (steel).....
27942	Thread Eyelet Rod.....
453c	“ “ “ Set Screw.....
27943	Thread Unwinder complete, Nos. 27938 to 27940, 27942, two 27941 and three wood screws 1 in. No. 12.....