


SINGER
95K30

LIST OF PARTS

FOR

No. 95K30
MACHINE



THE SINGER MANUFACTURING COMPANY.

PARTS COMPLETE
FOR
No. 95K30 MACHINE



For Thread Drawing. No Needles.

No.							
*99101	Arm with two 56015	(SK20022)	
16532	" Dowel Pin	
24131	" Oil Tube with 24500 ⁵²⁰⁴⁵ for oiling	24036	1/29
52084	" " " " 24500 ⁵²⁰⁴⁵ " "	24040	"
24500 ⁵²⁰⁴⁵	" " " Packing (Felt)		1/29
116e	" Screw (back)	
868e	" " (front)	
99437	" Shaft (horizontal)	
52059	" " (") Flanged Bushing (back)	
56006 ⁵²⁰⁴⁵	" " (") " " (") Oil Pad		1/29
						(Braided Cotton)	
446c	" " (") " " (") Set Screw	
52078	" " (") " " (front)	
56006 ⁵²⁰⁴⁵	" " (") " " (") Oil Pad		1/29
						(Braided Cotton)	
435c	" " (") " " (") Set Screw	
52060	" " (") Gear with two 1036c	
52071	" " (") " " Case (two pieces) with 121e and 50234d	
50234d	" " (") " " Plug Screw	
121e	" " (") " " Screw	
1036c	" " (") " " Set Screw	
144d	" " (") Screw	
52062	" " (upright)	
56099	" " (") Bushing (lower)	
432c	" " (") " " (") Set Screw	
56100	" " (") " " (upper)	
1149c	" " (") " " (") Set Screw	
56013	" " (") Gear (lower) with two 1253c	
1253c	" " (") " " (") Set Screw	
56101	" " (") " " (upper) with two 1253c	
1253c	" " (") " " (") Set Screw	
56015	" " (") Oil Tube (lower)	
56015	" " (") " " (upper)	
54897	" " Front Bearing Oil Cup	
12193	" Side Cover	
50053d	" " " Thumb Screw	

No.							
52081	Balance Wheel	(stand) heavy rim, 2 1/8" Pulley, with two 448c
52005	" "	(power) light rim, 2 3/8" pulley, with two 448c
52063	" "	Oil Cover
210d	" "	" " Screw
448c	" "	Set Screw
*99402	Bed	(SK20023)	
99403	" Slide	(SK20024)	
99404	" "	99403 with 662d and 19147	(SK20025)	
19147	" "	Spring
662d	" "	" Screw
99405	Face Plate	(SK20026)	
217d	" "	Screw (3)
99406	Feed Bar	(SK20027)	
313c	" "	Screw Centre
1519e	" "	" " Nut
3033	Feed Connecting Link
375c	" "	" Hinge Screw
1518e	" "	" " Nut
52073	" "	" " Stud
50083c	" "	" " Set Screw
99407	Feed Dog with 19118	(SK20028)	
191c	" "	Screw
19116	" "	Spring
19117	" "	" Hook
99408	Feed and Feed Lifting Eccentric with 448c	(SK20029)	
448c	" "	" " Set Screw
24036	" "	" " Sleeve
24037	Feed Forked Connection
375c	" "	" Hinge Screw
1518e	" "	" " Nut
99409	Feed Lifting Rock Shaft	(SK20030)	
99410	" "	" " complete, Nos. 19120 and 99409	(SK20031)	
12430	" "	" " Connecting Rod with 12204 and two 966e
*12204	" "	" " " Cap
966e	" "	" " " Screw
375c	" "	" " " Hinge Screw
1518e	" "	" " " " Nut
19120	" "	" " Crank with 157 ^c , 19117, 19121 and 19122
157 ^c	" "	" " Clamping Screw
19118	Feed Dog	Spring Hook for 99407

No.							
19121	Feed Lifting Rock Shaft	Crank Roller
19122	" "	" " " " " " Pin
50191c	" "	" " " " Screw Centre
1513j	" "	" " " " " " Nut
52074	Feed Regulator with 50083c
1128e	" "	" Hinge Screw
818d	" "	" Thumb Screw
52068	Feed Rock Shaft
52069	" "	" " complete, Nos. 29633 and 52068
29633	" "	" " Crank with 157 ^c
157 ^c	" "	" " Clamping Screw
50191c	" "	" " Screw Centre
1513j	" "	" " " " Nut
99411	Guide Adjustable Rod	(SK20168)	
99412	" "	" " Indicator	(SK20169)	
207d	" "	" " " " Screw
1191d	" "	" " " " Thumb Screw
27795	" "	" " " " " " Pad
99413	" Bracket	(SK20170)	
164d	" "	" " Screw
99414	" Strip	(SK20171)	
99415	" Bracket	(SK20172)	
453c	" "	" " " " Screw
190f	" "	" " " " Screw
99416	Guide, complete, Nos. 207d, 453c, 1191d, 27795, 99411 to 99415, two each 164d and 190f	(SK20173)	
12391	Presser Bar (hollow)
99417	" "	" " Guide Bracket with 223c and 453c	(SK20034)	
453c	" "	" " " " Set Screw
52016	" "	" " Lifter
689c	" "	" " " " Screw
1520r	" "	" " " " " " Nut
12327	" "	" " Lifting Lever Bracket
11167	" "	" " Spring
11170	" "	" " " " Washer
99418	Presser Foot (left)	(SK20035)	
50111e	" "	" (") Hinge Screw
99419	" "	" (right)	(SK20036)	
50111e	" "	" (") Hinge Screw
22162	" "	" Bracket
99420	" "	" Shank (left)	(SK20037)	
99421	" "	" " (right)	(SK20038)	
22166	" "	" " Cap with 2113

1/29
1/24

5/27

1/29

5/27

No.	Description	Part No.
2113	Presser Foot Shank Cap Position Pin	...
190d	" " " " Screw	...
22167	" " " Hinge Connection	...
99422	" " complete, Nos. 190d, 22162, 22166, 22167, 99418 to 99421 and two 50111e	(SK20039)
190d	" " Screw	...
688j	Pressure Regulating Thumb Screw	...
* 99423	Punch (Serrated) <i>obsolete, use 99447</i>	(SK20032) 7/29
99424	" Bar (hollow) with 857h	(SK20033)
52014 52305	" " Bushing (lower) with 29532	...
1133e	" " " (") Set Screw	...
52014	" " " (upper)	...
1133e	" " " (") Set Screw	...
24040	" " Connecting Link with 794e	...
794e	" " " Adjusting Screw	...
24041	" " " Stud with 207e	...
207e	" " " Clamping Screw	...
99425	" " Crank, with 743c, 858c and 1036c	...
99438	" " " complete, Nos. 99425, 99439 and two 161c	...
99439	" " " Eccentric	...
94548	" " " Oil Cup	...
161e	" " " Screw	...
743c	" " " Position Screw	...
858c	" " " Set Screw	...
99426	" " " Stud	...
1036c	" " " Set Screw	...
29532	" " Oil Cup	...
857h	" " Set Screw	...
* 99427	Rotating Knife (Adjustable)	(SK20365)
99440	" " Adjuster	(SK20366)
21202	" " Friction Washer	...
99428	" " Holder	(SK20041)
1147c	" " " Screw (2)	...
99429	" " Shaft	(SK20042)
56106	" " " Bushing (back)	...
52045	" " " " (") Packing (Cotton)	...
1143c	" " " " (") Set Screw	...
99430	" " " " (front)	(SK20043)
52045	" " " " (") Packing (Cotton)	...
1148c	" " " " (") Set Screw	...
56013	" " " Gear with two 1253c	...
52072	" " " Case (two pieces) with 121e and 50234d	...
50234d	" " " " " Plug Screw	...
121e	" " " " " Screw	...
* 99447	Punch (stepped, 3/8" wide)	...
+ 54897	Rotating Knife Holder Shaft Front Bearing Oil Cup	...
24894	— Punch Bar Connecting Link 24040 with 24011	...

No.	Description	Part No.
1253c	Rotating Knife Holder Shaft Gear Set Screw	...
1094d	" " Screw	...
99431	Throat Plate	(SK20044)
691f	" " Screw (+)	...
99432	Work Stretching Plunger (left)	(SK20045)
230d	" " " (") Screw	...
99433	" " " (right)	(SK20046)
230d	" " " (") Screw	...
99434	" " Bar with 2301	(SK20048)
24431	" " Driving Crank with 191c	...
99441	1162c " " " Coupling Pin	7/28
1564d	" " " " " Head	...
2297	" <i>obsolete</i> " " " Spring	"
2022	" " " Pin	...
191c	" <i>obsolete</i> " " " Set Screw	...
99446	Work Stretching Plunger Bar Driving Crank Bracket, complete, Nos. 1162c, 1564d, 16564, 24431, 99441 to 99445 and two 2022	...
99442	Work Stretching Plunger Bar Driving Sleeve with 191c	...
99443	" " " " " Eccentric Connection	...
99444	" " " " " Oil Cap with two 237d and 24432	...
237d	" " " " " Set Screw	v (2) ...
2022	" " " " " Pin	...
191c	" " " " " Set Screw	(SK20047)
99445	" " " " " Shaft	...
24079	Drip Pan, with four Wood Screws 1/2" No. 5	...

ACCESSORIES

No.	Description	Part No.
36569	Oiler with 36571	...
36570	" 36569, filled with Oil	...
36571	" Spout, 1 1/4" long	...
25537	Screw Driver (large)	...

KNEE LIFTER

No.								
5596	Bell Crank
5599	"	"	Bracket
178e	"	"	" Screw
5601 5601	"	"	Hinge Pin
5735	"	"	Spring
56848	"	"	5596 with 5599 and 5601
5598	Bell Crank , complete, Nos. 5735 and 56848
16585	Lifting Lever with 448c
52028	"	"	Connecting Rod
12416	"	"	" " Joint
76d	"	"	" " Hinge Screw
1521e	"	"	" " Lock Nut
802d	"	"	Hinge Screw
12241	"	"	Link
766d	"	"	" Hinge Screw
16586	"	"	Pin
448c	"	"	" Set Screw
2763	Rock Shaft
97502 80208	"	"	Bracket
—	"	"	" Screw (Wood), 1" No. 10
2765	"	"	Knee Arm
2766	"	"	" " Hub with 356c
356c	"	"	" " Set Screw
2768	"	"	" " 2765 with 2766 and 2767
2767	"	"	" Plate with 356c
356c	"	"	" " Set Screw
6337	"	"	Lifting Bracket with two 356c...
2778	"	"	" " Hook
356c	"	"	" " Set Screw
356c	"	"	" " Set Screw
2770	"	"	Stop Dog with 356c
356c	"	"	" " Set Screw...
84789	Rock Shaft 2763 with 2768, 2770, 2778, 6337, two 80208 ⁹²⁵⁰² and four Wood Screws, 1" No. 10
99436	Knee Lifter , complete, Nos. 76d, 766d, 802d, 1521e, 5598, 12241, 12416, 16585, 16586, 52028, 84789 and two 178e

5/27

11/28

11/28