


HISTORICAL COPY
DO NOT DESTROY
RETURN TO STATIONARY DEPARTMENT



Form 19447

(1139)

PRINTED IN U. S. A.



SINGER


241-2



HISTORICAL COPY
DO NOT DESTROY
RETURN TO STATIONARY DEPARTMENT


THE SINGER MANUFACTURING COMPANY



800 342 8357




Copyright, U. S. A., 1939
 by The Singer Manufacturing Co.
 All Rights Reserved for all Countries

23204 - 1/2






23210 - 1/2




INSERT IN PLACE OF PLATE
NOW SHOWING


22248 - 1/8




22919 - 2/3




22950 - 1/3




23213 - 1/2



23214 - 2/3




23215 - 1/3




23216 - 2/3


259452







23217 - 2/3







23218 - 2/3














28776

