

Form 3142w
(456)
Printed In U.S.A.

LIST OF PARTS
SINGER SEWING MACHINE**
107w100

THE SINGER MANUFACTURING COMPANY

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the PART number in the FIRST column.

The number stamped on a Sewing Machine Part is the number of the Single Part only, except when the part includes Set Screws, Clamping Screws, Studs and Rollers Spun on, Small Wires riveted, or Parts soldered together, etc., which it is necessary to furnish in combination.

Every combination of parts sent out has its specific number which, although not stamped on Parts (except in above case) must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever Machine.

The letters after some of the numbers indicate the style of finish only, as follows:

| | |
|-----|---|
| A | Hardened, Polished, Nickel Plated and Buffed. |
| AL | Heat Treated for Toughness. |
| ALX | Heat Treated for Toughness and Black Oxide. |
| B | Polished, Nickel Plated and Buffed. |
| C | Hardened only. |
| D | Polished only. |
| E | Soft, Not polished. |
| F | Hardened and Polished. |
| J | Nickel Plated only. |
| R | Merlized |
| X | Black Oxide, for Iron and Steel. |
| XC | Hardened and Black Oxide, for Iron and Steel. |
| Y | Black Nickel Plated only. |
| Z | Chromium Plated |

These letters MUST BE USED when they appear in the list and AFTER the number, as in the list.

In this series:

1 to 1500, 200001 to 201500 and 350001 to 351500 are Screw Numbers.
1501 to 1800, 201501 to 201800 and 351501 to 351800 are Nut Numbers.
1801 to 2000, 201801 to 202000 and 351801 to 352000 are Roller Numbers.
2001 to 50000 and 202001 to 350000 are Numbers of Machine Parts.

The figures in the second column refer only to the plate in which the illustration of the part is shown and are NOT TO BE USED in ordering. These Plates are in Form 20500, Illustrations of Parts.

Parts marked with an asterisk (*) are furnished only when repairs are made at the factory.

LIST OF PARTS COMPLETE
 FOR
 MACHINE NO. 107w100
 LOCK STITCH, LONG ARM MACHINE,
 DROP FEED, TRANSVERSE HOOK FOR
 MAKING THE ZIGZAG OR STRAIGHTAWAY
 LOCK STITCH, BELT DRIVEN,
 MAXIMUM STITCH 16 TO THE INCH,
 FOR EMBROIDERY WORK

| No. | Plate | Name |
|---------|-------|---|
| *224301 | ----- | Arm with 202135 |
| 203087 | 16825 | Arm Cap |
| 200278X | 10755 | Arm Cap Screw |
| 202248 | 10755 | Arm Cap Screw Washer |
| 203089 | 10751 | Arm Cap Spool Holder Base |
| 203090 | 16825 | Arm Cap Spool Holder Base 203089 with 200079X and 204296 |
| 200585X | 13155 | Arm Cap Spool Holder Base Screw |
| 204296 | 10751 | Arm Cap Spool Holder Wire |
| 200079X | 13155 | Arm Cap Spool Holder Wire Hinge Screw |
| 203088 | 16825 | Arm Cap and Spool Holder complete, Nos. 203087, 203090 and two 200585X |
| 204235 | 10755 | Arm Position Pin (2) |
| 200004E | 16826 | Arm Screw |
| 200010E | 10755 | Arm Screw (2) |
| 202005 | 10755 | Arm Screw Washer (3) |
| 202250 | 13163 | Arm Shaft with 224392 and 350431E |
| 240802 | 16825 | Arm Shaft Bushing (back) with 202244 |
| 202244 | 16825 | Arm Shaft Bushing (back) Oil Packing (wick) |
| 200338C | 10755 | Arm Shaft Bushing (back) Set Screw |
| 224423 | 18918 | Arm Shaft Bushing (front) with 202244 |
| 202244 | 16825 | Arm Shaft Bushing (front) Oil Packing (wick) |
| 200502X | 10755 | Arm Shaft Bushing (front) Oil Packing Thumb Screw |
| 200341C | 10755 | Arm Shaft Bushing (front) Set Screw |
| 224303 | 13151 | Arm Shaft Connection Belt |
| 202635 | 18927 | Arm Shaft Connection Belt Pulley with 200327C, 200602C and two 202253 |
| 200602C | 18927 | Arm Shaft Connection Belt Pulley Position Screw |
| 200327C | 18927 | Arm Shaft Connection Belt Pulley Set Screw |
| 202253 | 18927 | Arm Shaft Connection Belt Pulley Spring Flange |
| 224392 | 16825 | Arm Shaft Oil Packing (wick) |
| 350431E | 16825 | Arm Shaft Oil Packing Stop Screw |

PARTS FOR MACHINE NO.107w100

| No. | Plate | Name |
|----------|-------|--|
| *224304 | ----- | Bed |
| 210505 | 10751 | Bed Plate (back) |
| 200577AL | 10755 | Bed Plate (back) Screw (2) |
| 224305 | 13151 | Bed Slide (front) |
| 263099 | 18920 | Bobbin |
| 224416 | 18920 | Bobbin Case Base |
| 224417 | 18920 | Bobbin Case Cap with 200598C, 201016C and 224421 |
| 224418 | 18920 | Bobbin Case Cap complete, Nos. 200964C, 210736, 210914 and 224417 |
| 210913 | 18920 | Bobbin Case Latch |
| 210914 | 18920 | Bobbin Case Latch 210913 with 210734 and 210735 |
| 210735 | 18920 | Bobbin Case Latch Fulcrum Pin |
| 210734 | 18920 | Bobbin Case Latch Lever |
| 210736 | 18920 | Bobbin Case Latch Spring |
| 200964C | 18920 | Bobbin Case Latch Stop Screw |
| 224311 | 13152 | Bobbin Case Stop |
| 200076D | 13152 | Bobbin Case Stop Screw |
| 224421 | 18920 | Bobbin Case Tension Spring |
| 201016C | 18920 | Bobbin Case Tension Spring Regulating Screw |
| 200598C | 18920 | Bobbin Case Tension Spring Screw |
| 224419 | 18920 | Bobbin Case complete, Nos. 224416 and 224418 |
| 224314 | 13151 | Face Plate |
| 202135 | 10755 | Face Plate Position Pin |
| 200462X | 10755 | Face Plate Thumb Screw |
| 210512 | 18927 | Feed Bar |
| 224315 | 18927 | Feed Bar 210512 with 200641C, 201522E and 224321 |
| 200641C | 18927 | Feed Bar Hinge Screw (driving) |
| 201522E | 18927 | Feed Bar Hinge Screw Nut |
| 202276 | 10760 | Feed Bar Slide Block |
| 210514 | 10760 | Feed Bar Slide Block Crank with 200035E |
| 210515 | 10760 | Feed Bar Slide Block Crank 210514 with 200253C, 201531E and 202276 |
| 200035E | 10760 | Feed Bar Slide Block Crank Pinch Screw |
| 200253C | 16827 | Feed Bar Slide Block Hinge Screw |
| 201531E | 10760 | Feed Bar Slide Block Hinge Screw Nut |
| 224316 | 13153 | Feed Dog, for 224380 |
| 200106E | 10755 | Feed Dog Screw (2) |
| 202297 | 13154 | Feed Driving Connection with 200054E and 203101 |
| 202624 | 10760 | Feed Driving Connection Crank with 200038C |
| 200038C | 10760 | Feed Driving Connection Crank Pinch Screw |
| 200545C | 10760 | Feed Driving Connection Hinge Screw |
| 201518E | 10755 | Feed Driving Connection Hinge Screw Nut |
| 203101 | 18920 | Feed Driving Connection Oil Packing (wick) |
| 200054E | 10755 | Feed Driving Connection Pinch Screw |
| 233147 | 18927 | Feed Driving Eccentric Regulating Bracket |
| 233174 | 18927 | Feed Driving Eccentric Regulating Bracket 233147 with 202635, two each 201014C and 201525E |
| 201014C | 18927 | Feed Driving Eccentric Regulating Bracket Hinge Screw |

PARTS FOR MACHINE NO.107w100

| No. | Plate | Name |
|---------|-------|---|
| 201525E | 18927 | Feed Driving Eccentric Regulating Bracket Hinge Screw Nut |
| 202301 | 10755 | Feed Driving Eccentric Regulating Bracket Plunger |
| 202595 | 10755 | Feed Driving Eccentric Regulating Bracket Plunger Spring |
| 200607C | 10755 | Feed Driving Eccentric Regulating Bracket Plunger Spring Stop Screw |
| 201014C | 13155 | Feed Driving Eccentric Regulating Bracket Stop Screw |
| 201525E | 10755 | Feed Driving Eccentric Regulating Bracket Stop Screw Nut |
| 200429F | 10755 | Feed Driving Eccentric Regulating Screw |
| 200383C | 10755 | Feed Driving Eccentric Regulating Screw Check Screw |
| 224321 | 18927 | Feed Driving Rock Shaft |
| 202625 | 10760 | Feed Driving Rock Shaft Stop Collar with two 200383C (2) |
| 200383C | 10755 | Feed Driving Rock Shaft Stop Collar Set Screw |
| 202306 | 13154 | Feed Lifting Connection with 200054E and 203101 |
| *210645 | ----- | Feed Lifting Connection Crank |
| 210589 | 10760 | Feed Lifting Connection Crank 210645 with 200050C and 200378C |
| 200050C | 10760 | Feed Lifting Connection Crank Pinch Screw |
| 200378C | 10760 | Feed Lifting Connection Crank Set Screw |
| 202307 | 10760 | Feed Lifting Connection Eccentric with 200382C and 200437C |
| 200437C | 10760 | Feed Lifting Connection Eccentric Position Screw |
| 200382C | 10793 | Feed Lifting Connection Eccentric Set Screw |
| 200545C | 10760 | Feed Lifting Connection Hinge Screw |
| 201518E | 10755 | Feed Lifting Connection Hinge Screw Nut |
| 203101 | 18920 | Feed Lifting Connection Oil Packing (wick) |
| 200054E | 10755 | Feed Lifting Connection Pinch Screw |
| 224322 | 13154 | Feed Lifting Rock Shaft |
| 202625 | 10760 | Feed Lifting Rock Shaft Stop Collar with two 200383C |
| 200383C | 10755 | Feed Lifting Rock Shaft Stop Collar Set Screw |
| 202310 | 16825 | Feed Regulating Spindle with 202311, 202443 and 202619 |
| *202311 | ----- | Feed Regulating Spindle Head |
| 202443 | 13155 | Feed Regulating Spindle Head Pin |
| 202619 | 13155 | Feed Regulating Spindle Head Position Pin |
| *224427 | ----- | Hook (sewing) |
| 224428 | 18920 | Hook 224427 with 200145C, 203101, 224330, 224339 and three 200596F |
| 224325 | 18920 | Hook and Bobbin Case complete, Nos. 224419 and 224428 |
| 224422 | 13155 | Hook Driving Gear (spiral) with 200383C and 200398C |
| 200398C | 13155 | Hook Driving Gear Position Screw |
| 200383C | 10755 | Hook Driving Gear Set Screw |
| 224326 | 13163 | Hook Driving Gear Shaft |
| 202661 | 10753 | Hook Driving Gear Shaft Belt Pulley with 202324 and two 200378C |

PARTS FOR MACHINE NO.107w100

| No. | Plate | Name |
|----------|-------|--|
| 200378C | 10760 | Hook Driving Gear Shaft Belt Pulley Set Screw |
| 202324 | 10757 | Hook Driving Gear Shaft Belt Pulley Spring Flange |
| 224327 | 13155 | Hook Driving Gear Shaft Bushing (back) |
| 200362C | 10793 | Hook Driving Gear Shaft Bushing (back) Set Screw |
| 224328 | 13155 | Hook Driving Gear Shaft Bushing (front) |
| 200346C | 13155 | Hook Driving Gear Shaft Bushing (front) Set Screw |
| 202260 | 17724 | Hook Driving Gear Shaft Oil Packing (wick) |
| 224329 | 13155 | Hook Gear (spiral) with two 200383C |
| 200383C | 10755 | Hook Gear Set Screw |
| 224330 | 18920 | Hook Gib |
| 200596F | 18920 | Hook Gib Screw |
| 203101 | 18920 | Hook Oil Wick |
| 200915F | 10757 | Hook Position Screw |
| 210537 | 10757 | Hook Shaft (hollow) |
| 210539 | 10757 | Hook Shaft Bushing |
| 210621 | 18919 | Hook Shaft Bushing 210539 with 210537 and 350314F |
| 224392 | 18919 | Hook Shaft Bushing Oil Packing (wick) |
| 200335C | 10755 | Hook Shaft Bushing Set Screw |
| 200363AL | 13155 | Hook Shaft Bushing Set Screw |
| 244084 | 18919 | Hook Shaft Bushing Set Screw Packing (fibre) |
| 350314C | 16827 | Hook Shaft Position Screw |
| 224331 | 13154 | Hook Timing Lever |
| 224332 | 13155 | Hook Timing Lever Connecting Link |
| 201213C | 13155 | Hook Timing Lever Connecting Link Hinge Screw Stud |
| 201520C | 10793 | Hook Timing Lever Connecting Link Hinge Screw Stud Nut |
| 224333 | 13155 | Hook Timing Lever Connecting Swivel with 202277 |
| 202277 | 15975 | Hook Timing Lever Connecting Swivel Oil Packing (wick) |
| 224335 | 13155 | Hook Timing Lever Connecting Swivel Stop Collar with two 201052C |
| 201052C | 13155 | Hook Timing Lever Connecting Swivel Stop Collar Set Screw |
| 224336 | 13154 | Hook Timing Lever Driving Arm |
| 224337 | 13155 | Hook Timing Lever Driving Arm Bearing |
| 200252C | 13155 | Hook Timing Lever Driving Arm Hinge Screw |
| 201528F | 10793 | Hook Timing Lever Driving Arm Hinge Screw Nut |
| 202622 | 13155 | Hook Timing Lever Driving Arm Washer |
| 224386 | 13154 | Hook Timing Lever Shaft with 224390 |
| 204197 | 13155 | Hook Timing Lever Shaft Collar with 200113F |
| 200113F | 10793 | Hook Timing Lever Shaft Collar Set Screw |
| 224390 | 16816 | Hook Timing Lever Shaft Oil Packing (wick) |
| 200363AL | 13155 | Hook Timing Lever Shaft Set Screw |
| 224388 | 16816 | Hook Timing Lever and Needle Bar Frame Pitman complete, Nos. 200252C, 201180C, 201181C, 201213C, 201518E, 201520C, 201522E, 201528F, 202622, 224331 to 224333, 224336, 224337, 224344, 224352 and 224353 |

PARTS FOR MACHINE NO. 107w100

| No. | Plate | Name |
|----------|-------|--|
| 224339 | 18920 | Hook Washer Needle Guard |
| 200145C | 18920 | Hook Washer Needle Guard Screw |
| 244090 | 18913 | Machine Pulley (disc) (aluminum alloy casting) "V" belt groove (outside diam. of belt groove 2.9 in.) with 350540C and 350541C |
| 350540C | 18913 | Machine Pulley Position Screw |
| 350541C | 18913 | Machine Pulley Set Screw |
| 233122 | 13165 | Needle Bar with 200141F |
| 224340 | 13156 | Needle Bar Connecting Link |
| 224341 | 13156 | Needle Bar Connecting Link Stud with 202254 |
| 202254 | 16818 | Needle Bar Connecting Link Stud Oil Packing (wick) |
| 200374AL | 10761 | Needle Bar Connecting Link Stud Set Screw |
| 200383C | 10755 | Needle Bar Connecting Link Stud Set Screw |
| 210544 | 10761 | Needle Bar Connecting Stud with 202299 |
| 210585 | 16818 | Needle Bar Connecting Stud 210544 with 210882 |
| 202299 | 18910 | Needle Bar Connecting Stud Oil Packing (wick) |
| 210882 | 18910 | Needle Bar Connecting Stud Swivel with 200387C |
| 224342 | 13158 | Needle Bar Crank with 200335C, 200374AL, 200383C, 200428C and 224341 |
| 224384 | 16818 | Needle Bar Crank 224342 with 202399, 202400, 210585, 224340 and 224372 |
| 203172 | 10761 | Needle Bar Crank Friction Washer |
| 200428C | 10761 | Needle Bar Crank Position Screw |
| 200335C | 10755 | Needle Bar Crank Set Screw |
| 224343 | 13158 | Needle Bar Frame with 200070C |
| 210547 | 13156 | Needle Bar Frame Guide Stud |
| 200334C | 13156 | Needle Bar Frame Guide Stud Set Screw |
| 210548 | 13156 | Needle Bar Frame Hinge Stud |
| 200334C | 13156 | Needle Bar Frame Hinge Stud Set Screw |
| 224344 | 13158 | Needle Bar Frame Pitman |
| 210557 | 13156 | Needle Bar Frame Pitman Eccentric Stud |
| 200070C | 13156 | Needle Bar Frame Pitman Eccentric Stud Set Screw |
| 224346 | 13158 | Needle Bar Position Bracket with 200378C and 200917C |
| 200917C | 10793 | Needle Bar Position Bracket Position Screw |
| 200378C | 10760 | Needle Bar Position Bracket Set Screw |
| 224347 | 13158 | Needle Bar Position Lever with 200378C and 200917C |
| 201182E | 13156 | Needle Bar Position Lever Locking Screw Stud |
| 224348 | 13156 | Needle Bar Position Lever Locking Screw Stud Cap |
| 205526 | 13156 | Needle Bar Position Lever Locking Screw Stud Spring |
| 200917C | 10793 | Needle Bar Position Lever Position Screw |
| 200378C | 10760 | Needle Bar Position Lever Set Screw |
| 224389 | 16817 | Needle Bar Position Lever complete, Nos. 201182E, 205526, 224347 and 224348 |
| 200387C | 10793 | Needle Bar Set Screw |
| 200141F | 10761 | Needle Set Screw |
| 224424 | 16816 | Needle Vibrator Cam with 200378C and 200383C |
| 200378C | 10760 | Needle Vibrator Cam Set Screw |

PARTS FOR MACHINE NO.107w100

| No. | Plate | Name |
|---------|-------|---|
| 200383C | 10755 | Needle Vibrator Cam Set Screw |
| 210718 | 13158 | Needle Vibrator Cam Shaft |
| 224351 | 13159 | Needle Vibrator Cam Shaft Bearing and Cover |
| 200566D | 13156 | Needle Vibrator Cam Shaft Bearing and Cover Screw (3) |
| 210559 | 13156 | Needle Vibrator Cam Shaft Collar with two 200378C |
| 200378C | 10760 | Needle Vibrator Cam Shaft Collar Set Screw |
| 224352 | 13156 | Needle Vibrator Crank with 200382C and 200917C |
| 224353 | 13165 | Needle Vibrator Crank Link |
| 201180C | 13156 | Needle Vibrator Crank Link Hinge Screw (lower) |
| 201522E | 16816 | Needle Vibrator Crank Link Hinge Screw (lower) Nut |
| 201181C | 13156 | Needle Vibrator Crank Link Hinge Screw (upper) |
| 201518E | 10755 | Needle Vibrator Crank Link Hinge Screw (upper) Nut |
| 208554 | 16816 | Needle Vibrator Crank Oil Tube (brass) |
| 200917C | 10793 | Needle Vibrator Crank Position Screw |
| 200382C | 10793 | Needle Vibrator Crank Set Screw |
| 224354 | 13157 | Needle Vibrator Crank Shaft |
| 224355 | 13157 | Needle Vibrator Crank Shaft and Needle Bar Position Lever Connection |
| 210699 | 19102 | Needle Vibrator Gear (spiral) with two 200382C |
| 200382C | 10793 | Needle Vibrator Gear Set Screw |
| 203172 | 10761 | Needle Vibrator Gear Thrust Washer |
| 224409 | 13158 | Needle Vibrator Operating Bell Crank |
| 200224X | 10759 | Needle Vibrator Operating Bell Crank Hinge Screw |
| 224410 | 13157 | Needle Vibrator Operating Bell Crank Link |
| 200281D | 13157 | Needle Vibrator Operating Bell Crank Link Hinge Screw (2) |
| 224358 | 13157 | Needle Vibrator Operating Lever with 200378C and 200917C |
| 200917C | 10793 | Needle Vibrator Operating Lever Position Screw |
| 200378C | 10760 | Needle Vibrator Operating Lever Set Screw |
| 224415 | 13163 | Needle Vibrator Operating Rod with 202302 |
| 202302 | 13165 | Needle Vibrator Operating Rod Cotter Pin |
| 224411 | 13164 | Needle Vibrator Operating Rod Roller |
| 224412 | 13164 | Needle Vibrator Operating Rod Roller Bracket with 200113F |
| 200113F | 10793 | Needle Vibrator Operating Rod Roller Bracket Set Screw |
| 200270X | 13165 | Needle Vibrator Operating Rod Roller Hinge Screw |
| 224413 | 16817 | Needle Vibrator Operating Rod Roller Bracket complete, Nos. 200270X, 224411 and 224412 |
| 210700 | 19101 | Needle Vibrator Pinion (spiral) with two 200382C |
| 200382C | 10793 | Needle Vibrator Pinion Set Screw |
| 224407 | 13164 | Needle Vibrator Spring |
| 201284E | 13165 | Needle Vibrator Spring Screw Stud |
| 224408 | 13164 | Needle Vibrator Spring Screw Stud Collar with two 200113F |

PARTS FOR MACHINE NO.107w100

| No. | Plate | Name |
|-----------|-------|---|
| 200113F | 10793 | Needle Vibrator Spring Screw Stud Collar Set Screw |
| 224360 | 13157 | Needle Vibrator Stop Bracket with two 200374AL (for width of throw) |
| 200374AL | 10761 | Needle Vibrator Stop Bracket Set Screw |
| 224381 | 13160 | Needle Vibrator Stop Index Finger |
| 200330C | 13160 | Needle Vibrator Stop Screw (for zero stops) (3) |
| 200340ALX | 16817 | Needle Vibrator Stop Screw Set Screw (3) |
| 224361 | 13160 | Needle Vibrator Stop Screw Set Screw Packing (brass) (3) |
| 224382 | 13160 | Needle Vibrator Stop Segment |
| 201638D | 13160 | Needle Vibrator Stop Segment Locking Nut |
| 201179E | 13160 | Needle Vibrator Stop Segment Locking Nut Check Screw |
| 224383 | 13160 | Needle Vibrator Stop Segment Locking Nut Washer |
| 200077D | 13160 | Needle Vibrator Stop Segment Screw |
| 213791 | 13159 | Presser Bar (hollow) |
| 224391 | 13160 | Presser Bar Bushing |
| 200352AL | 10759 | Presser Bar Bushing Set Screw |
| 202554 | 10759 | Presser Bar Lifter |
| 200653C | 10759 | Presser Bar Lifter Hinge Screw |
| 210789 | 19103 | Presser Bar Lifting Releasing Lever Bracket |
| 200260E | 10759 | Presser Bar Lifting Releasing Lever Bracket Guide Screw |
| 206608 | 19103 | Presser Bar Lifting Releasing Lever Bracket Spring |
| 202337 | 10759 | Presser Bar Position Guide |
| 202338 | 10759 | Presser Bar Position Guide Lever with 200086F |
| 200086F | 10759 | Presser Bar Position Guide Lever Pinch Screw |
| 200352AL | 10759 | Presser Bar Position Guide Set Screw |
| 202378 | 13160 | Presser Bar Spring |
| 202346 | 10751 | Presser Bar Spring Stop Rod |
| 200492X | 10759 | Presser Bar Thumb Screw (pressure regulating) |
| 200475X | 10759 | Presser Bar Thumb Screw Thumb Set Screw |
| 244084 | 19103 | Presser Bar Thumb Screw Thumb Set Screw Packing (fibre) |
| 224362 | 18928 | Presser Foot Bracket with 200097C |
| 200097C | 18928 | Presser Foot Bracket Screw |
| 224363 | 18928 | Presser Foot Hinge Connection |
| 200278X | 18928 | Presser Foot Hinge Connection Hinge Screw |
| 224393 | 18928 | Presser Foot Plate (left) |
| 224394 | 18928 | Presser Foot Plate 224393 with 204264 and 224368 |
| 224395 | 18928 | Presser Foot Plate (right) |
| 224396 | 18928 | Presser Foot Plate 224395 with 204264 and 224368 |
| 204264 | 18928 | Presser Foot Plate Hinge Pin |
| 224368 | 18928 | Presser Foot Shank (left or right) |
| 224369 | 18928 | Presser Foot Slide Plate |
| 200077D | 18928 | Presser Foot Slide Plate Screw |
| 224397 | 18928 | Presser Foot (hinged) (compensating) complete, Nos. 200278X, 224362, 224363, 224394, 224396, four each 200077D and 224369 |

PARTS FOR MACHINE NO.107w100

| No. | Plate | Name |
|-----------|-------|--|
| 224371 | 13162 | Take-up (auxiliary) |
| 200132E | 10761 | Take-up (auxiliary) Screw |
| 224372 | 13162 | Take-up Lever |
| 202399 | 18910 | Take-up Lever Driving Stud with 202277 |
| 202277 | 18910 | Take-up Lever Driving Stud Oil Packing (wick) |
| 202400 | 18910 | Take-up Lever Hinge Stud with 202423 |
| 202423 | 18910 | Take-up Lever Hinge Stud Oil Packing (wick) |
| 200383C | 10755 | Take-up Lever Hinge Stud Set Screw |
| 202401 | 10761 | Take-up Lever Oiling Felt |
| 200132E | 10761 | Take-up Lever Oiling Felt Screw |
| 244048 | 18921 | Tension Disc (back) |
| 244049 | 18921 | Tension Disc (front) |
| 224402 | 18923 | Tension Release Lever |
| 224403 | 13164 | Tension Release Lever 224402 with 200289E, 201537X and 224404 |
| 200289E | 10793 | Tension Release Lever Hinge Screw |
| 201537X | 10272 | Tension Release Lever Hinge Screw Nut |
| 224404 | 18923 | Tension Release Lever Hinge Stud |
| 200389C | 13165 | Tension Release Lever Hinge Stud Set Screw |
| 202404 | 10762 | Tension Release Plunger |
| 202405 | 10762 | Tension Release Washer |
| 202407 | 18921 | Tension Spring |
| 200625F | 18921 | Tension Stud with 204925 |
| 200061ALX | 18921 | Tension Stud Set Screw |
| 204925 | 18921 | Tension Stud Washer |
| 201572X | 18921 | Tension Thumb Nut |
| 202409 | 18921 | Tension complete, Nos. 200625F, 201572X, 202405, 202407, 202410, 244048 and 244049 |
| 201184J | 18921 | Thread Controller Bearing (screw) |
| 201637X | 18921 | Thread Controller Bearing Check Nut |
| 244048 | 18921 | Thread Controller Disc |
| 224405 | 18921 | Thread Controller Disc Cap |
| 200577AL | 18921 | Thread Controller Disc Cap Screw |
| 224373 | 18921 | Thread Controller Disc Position Pin |
| 224374 | 18921 | Thread Controller Releasing Plunger |
| 224375 | 13162 | Thread Controller Releasing Plunger Roller |
| 224376 | 18921 | Thread Controller Releasing Plunger Spring |
| 202410 | 18921 | Thread Controller Spring |
| 241443 | 18921 | Thread Controller Spring Stop |
| 200132E | 18921 | Thread Controller Spring Stop Screw |
| 224406 | 18921 | Thread Controller complete, Nos. 200577AL, 201184J, 201637X, 224373, 224374, 224376, 224405 and two 244048 |
| 224387 | 16818 | Thread Guide |
| 210788 | 18921 | Thread Guide |
| 210592 | 18921 | Thread Guide (upper) |
| 200172X | 16818 | Thread Guide Screw |
| 200582X | 18921 | Thread Guide Screw (2) |

PARTS FOR MACHINE NO.107w100

| No. | Plate | Name |
|----------|-------|--------------------------|
| 224380 | 13153 | Throat Plate, for 224316 |
| 200577AL | 10755 | Throat Plate Screw (2) |

ACCESSORIES

| No. | Plate | Name |
|---------|-------|--|
| 200157E | 13162 | Attachment Screw |
| 263099 | 18920 | Bobbin (2) |
| 231337 | 10776 | Cloth Guide |
| 228213 | 17657 | Drip Pan (long) with four 3/4 in. wire nails |
| 208676 | 18922 | Embroidery Hoop, 12 inch |
| 210844 | 16286 | Machine Hinge Connection (2) |
| 200060E | 16286 | Machine Hinge Connection Screw (4) |
| 41400 | 10776 | Machine Rest Pin (wood) |
| 135x7 | ----- | Needles, six, size 16 |
| 120342 | 17010 | Oiler (copper plated) with 120343 |
| 120343 | 17010 | Oiler Spout, 3-1/2 in. long |
| 228476 | 17010 | Screw Driver (Bobbin Case) |
| 225498 | 17851 | Screw Driver (7-1/4 in. long) |
| 225554 | 10776 | Wrench (steel) |

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)

FOR "V" BELT DRIVE

| | | |
|---------|-------|-----------------------------------|
| 259428 | 17853 | Brake (leather) |
| 259429 | 17853 | Brake Clamp |
| 200113F | 17853 | Brake Clamp Screw |
| 225453 | 17853 | Frame with 202277 and 259660 |
| 225454 | 17853 | Frame Hinge Pin |
| 202277 | 17853 | Frame Oil Packing (wick) |
| 259660 | 17853 | Frame Oil Well Washer |
| 225455 | 17853 | Frame Spring |
| 225456 | 17853 | Frame Spring Plunger |
| 259461 | 17853 | Pulley with 200380C |
| 200380C | 17853 | Pulley Set Screw |
| 225381 | 17853 | Spindle |
| 225444 | 17853 | Stop Latch |
| 200056E | 17853 | Stop Latch Screw |
| 225458 | 17853 | Stop Latch Thumb Lever |
| 225459 | 17853 | Stop Latch Thumb Lever Hinge Stud |

ACCESSORIES

| No. | Plate | Name |
|---------|-------|--|
| 225459 | 17853 | Stop Latch Thumb Lever Joint Stud |
| 202478 | 17853 | Stop Latch Trip Lever |
| 200299X | 17853 | Stop Latch Trip Lever Hinge Screw |
| 225461 | 17853 | Tension Bracket with 201499X |
| 200082D | 17853 | Tension Bracket Screw |
| 228026 | 17853 | Tension Bracket Screw Washer |
| 2102 | 17853 | Tension Disc |
| 13710 | 17853 | Tension Spring |
| 201499X | 17853 | Tension Stud |
| 201572X | 17853 | Tension Stud Thumb Nut |
| 225462 | 17853 | Bobbin Winder Tension Bracket complete, Nos. 13710, 201572X, 225461 and two 2102 |
| 259662 | 17853 | Bobbin Winder and Tension Bracket Base |
| 259462 | 17853 | Universal Bobbin Winder complete, Nos. 200056E, 200082D, 200113F, 200299X, 202478, 225381, 225444, 225453 to 225456, 225458, 225462, 228026, 259428, 259429, 259461, 259662, two each 225459 and wood screws 3/4 in., No. 12, R. H. B. |

Note: Bobbin Winder 259462 is furnished with this Machine unless Bobbin Winder 259431 is specified on order

KNEE LIFTER

| | | |
|----------|-------|---|
| 228713 | 18580 | Rock Lever with two 350231C |
| 228707 | 18580 | Rock Lever Bracket with 200347AL and three wood screws 7/8 in., No. 12 |
| 228709 | 18580 | Rock Lever Bracket 228707 with 228363, 228367, 228386, 228455 and 228713 |
| 228370 | 18580 | Rock Lever Extension with 200530C |
| 350231C | 18580 | Rock Lever Extension Set Screw |
| 228363 | 18580 | Rock Lever Hinge Pin |
| 228364 | 18580 | Rock Lever Knee Plate with 350231C |
| 228388 | 18580 | Rock Lever Knee Plate Arm |
| 350231C | 18580 | Rock Lever Knee Plate Arm Set Screw |
| 350231C | 18580 | Rock Lever Knee Plate Set Screw |
| 228455 | 18580 | Rock Lever Position Spring |
| 228365 | 18580 | Rock Lever Rod |
| 200530C | 18580 | Rock Lever Rod Set Screw |
| 228386 | 18580 | Rock Lever Spring |
| 228367 | 18580 | Rock Lever Stop Stud |
| 200347AL | 18580 | Rock Lever Stop Stud Set Screw |
| 228710 | 18580 | Knee Lifter Rock Lever complete, Nos. 228364, 228365, 228370, 228388 and 228709 |